



Republic of the Philippines
DEPARTMENT OF PUBLIC WORKS AND HIGHWAYS
OFFICE OF THE SECRETARY
Manila

897.13 DPWH
01-16-2018

12 JAN 2018

DEPARTMENT ORDER)
NO. 05)
Series of 2018 *01.16.18*

**SUBJECT: Preventive Maintenance Manual
for DPWH Most Commonly Used
Equipment and Service Vehicles**

With the Department's systematic approach for the optimum utilization of physical assets and their associated performance, operational risks and safety program to ensure reliability of land-based equipment fleet throughout its life cycle, all concerned Offices and personnel are hereby directed to strictly implement and use the work procedures prescribed in this *Manual*.

The *Handbook* standardizes the proactive maintenance activities and times for each equipment type, providing a prompt ready guide for mechanics, electricians, operators/drivers and equipment shop personnel in conducting maintenance activities in a safe, efficient and effective manner.

The said *Manual* may be downloaded from the DPWH Intranet (<http://dpwhweb>).

This Order shall take effect immediately.

MARK A. VILLAR
Secretary

9.1.2 PRCJ/OOI/TNLI

Department of Public Works and Highways
Office of the Secretary



WIN8T01790

**PREVENTIVE MAINTENANCE MANUAL FOR DPWH
MOST COMMONLY USED EQUIPMENT AND SERVICE
VEHICLES**

2017

FOREWORD

With the intention to achieve optimum utilization of our equipment, the conduct of proper preventive maintenance shall be strictly enforced. Any delay to equipment operations and productions caused by equipment downtime in undertaking preventive maintenance, will be recovered many times over thru the reliability of performance and freedom from more expensive damage which would possibly take the equipment out of service for a greater period of time.

This Handbook on Preventive Maintenance, with its compact size, contains concise sequence of maintenance activities, complete with hazards involved and safety reminders. It shall serve as an effective ready reference and procedural handbook for our mechanics, electricians and shop equipment personnel in performing Active Maintenance Time.

With the adoption of this Manual, the Department expects to minimize downtime and prolong serviceable life of our equipment.



MARK A. VILLAR

Secretary

Department of Public Works and Highways
Office of the Secretary



WIN8T01790

OBJECTIVES

The Equipment Management System of the Department is to strategically manage capable and adequate land-based equipment fleet throughout its life cycle. Purposely plans at keeping and restoring this equipment assets to serviceable condition at all times, in support for road maintenance, flood control, disaster response and other related emergency situations.

As part of our Equipment Preventive Maintenance Program Policy, relative to the issuance of Department Order Nos. 63 and 64, both Series of 2016, this Manual describes the procedures as a guide for the correct use and application of active maintenance time, aims at increasing equipment uptime and reliability, and reduce operational safety risks.

INTRODUCTION

Preventive Maintenance (PM) is a series of inspection, lubrication and repair operations carried out on a predetermined interval or according to prescribed criteria and intended to reduce the probability of failure or malfunctioning of equipment and motor vehicles. It requires periodic inspection and maintenance schedules to eliminate the possibility of the onset of the elements of premature breakdown, and ensure utmost economy and the extended life of the equipment.

Categories of Preventive Maintenance

PM Schedule	<i>When Done</i>
Daily Maintenance	<i>Before equipment operation</i>
Periodic Maintenance:	
PM 1	<i>Every 50 hours or 1,000 kilometers</i>
PM 2	<i>Every 250 hours or 5,000 kilometers</i>
PM 3	<i>Every 500 hours or 10,000 kilometers</i>
PM 4	<i>Every 1,000 hours or 20,000 kilometers</i>
Rehabilitation	<i>Usage of 3,500 hours or 70,000 kilometers</i>

Under Section G, Item No. 3 as per DO No. 64 Series of 2016, the Area Equipment Section (AES) under the Equipment Management Division of the Regional Office (RO) and the Equipment Services Unit (ESU) under the Maintenance Section of the District Engineering Office (DEO) shall be jointly responsible in undertaking the PMs 2, 3, and 4, according to the above schedules.

In addition, the ESU shall be solely responsible in undertaking PM 1, as monitored and certified by the AES, while the operator/driver shall ensure the upkeep of all equipment and motor vehicle thru a daily/routine maintenance prescribed under DO No. 11 Series of 2016, with subject "Routine Maintenance for Service Vehicles and Most Commonly Used Equipment Manual."

Always adhere to the equipment manufacturer's Operation and Maintenance Manual for further details and safety instructions.

TABLE OF CONTENTS

LEGEND

1.0. Hydraulic Crane (F4/F5)	1
1.1. Engine Oil: Change	2
1.2. Engine Oil Filter: Replace	3
1.3. Primary Air Filter: Clean and Replace	4
1.4. Hydraulic Drain Filter: Replace	5
1.5. Swing Gear Bearing: Greasing	6
1.6. Arm and Front Attachments Pins: Greasing	7
1.7. Engine Fan Belt: Check/Replace	8
1.8. Axle Carrier Oil Level: Check	9
1.9. Axle Hub Oil Level: Check	10
1.10. Swing Drive Unit Oil: Change	11
1.11. Swing Bath Grease: Check/Change	12
1.12. Fuel Filter: Replace	13
1.13. Controls: Check/Adjust/Lubricate	14
1.14. Air-conditioning System: Check/Clean	15
1.15. Alternator Assembly: Check/Inspect	16
1.16. Starting Motor: Check/Inspect	17
1.17. Water Separator Element: Change	18
1.18. Hydraulic Oil: Change	19
1.19. Hydraulic Pilot Filter: Replace	20
1.20. Transfer Gearbox Oil: Change	21
1.21. Transfer Gearbox: Air Bleeding	22
1.22. Travel Reduction Device Oil: Change	23
1.23. Axle Carrier Oil: Change	24
1.24. Axle Hub Oil: Change	25
1.25. Hydraulic System: Venting and Priming	26
1.26. A. Check/Adjust Engine Valve Clearance	27
B. Check/Retight Cylinder Head Bolt	27
1.27. Turbocharger: Check/Clean	28
1.28. Track Tension: Check/Adjust	29
1.29. Air Conditioner Refrigerant: Check	30
2.0. Hydraulic Excavator (F16/F17)	31
2.1. Engine Oil: Change	32
2.2. Engine Oil Filter: Replace	33

2.3. Primary Air Filter: Clean and Replace	34
2.4. Hydraulic Drain Filter: Replace	35
2.5. Swing Gear Bearing: Greasing	36
2.6. Arm and Front Attachments Pins: Greasing	37
2.7. Engine Fan Belt: Check/Replace	38
2.8. Axle Carrier Oil Level: Check	39
2.9. Axle Hub Oil Level: Check	40
2.10. Swing Drive Unit Oil: Change	41
2.11. Swing Bath Grease: Check/Change	42
2.12. Fuel Filter: Replace	43
2.13. Controls: Check/Adjust/Lubricate	44
2.14. Air-conditioning System: Check/Clean	45
2.15. Alternator Assembly: Check/Inspect	46
2.16. Starting Motor: Check/Inspect	47
2.17. Water Separator Element: Change	48
2.18. Hydraulic Oil: Change	49
2.19. Hydraulic Pilot Filter: Replace	50
2.20. Transfer Gearbox Oil: Change	51
2.21. Transfer Gearbox: Air Bleeding	52
2.22. Travel Reduction Device Oil: Change	53
2.23. Axle Carrier Oil: Change	54
2.24. Axle Hub Oil: Change	55
2.25. Hydraulic System: Venting and Priming	56
2.26. A. Check/Adjust Engine Valve Clearance	57
B. Check/Retight Cylinder Head Bolt	57
2.27. Turbocharger: Check/Clean	58
2.28. Track Tension: Check/Adjust	59
2.29. Air Conditioner Refrigerant: Check	60
3.0. Service Vehicle (H1)	61
3.1. Engine Oil: Change	62
3.2. Engine Oil Filter: Replace	63
3.3. Engine Fan Belt: Check/Replace	64
3.4. Axle Carrier Oil Level: Check	65
3.5. Axle Hub Oil Level: Check	66
3.6. Fuel Filter: Replace	67
3.7. Controls: Check/Adjust/Lubricate	68
3.8. Air-conditioning System: Check/Clean	69
3.9. Alternator Assembly: Check/Inspect	70
3.10. Starting Motor: Check/Inspect	71
3.11. Transfer Gearbox Oil: Change	72
3.12. Transfer Gearbox: Air Bleeding	73

3.13. Axle Carrier Oil: Change	74
3.14. Axle Hub Oil: Change	75
3.15. A. Check/Adjust Engine Valve Clearance	76
B. Check/Retight Cylinder Head Bolt	76
3.16. Turbocharger: Check/Clean	77
3.17. Air Conditioner Refrigerant: Check	78
4.0. Dump Truck (H3)	79
4.1. Engine Oil: Change	80
4.2. Engine Oil Filter: Replace	81
4.3. Primary Air Filter: Clean and Replace	82
4.4. Hydraulic Drain Filter: Replace	83
4.5. Engine Fan Belt: Check/Replace	84
4.6. Axle Carrier Oil Level: Check	85
4.7. Axle Hub Oil Level: Check	86
4.8. Fuel Filter: Replace	87
4.9. Controls: Check/Adjust/Lubricate	88
4.10. Air-conditioning System: Check/Clean	89
4.11. Alternator Assembly: Check/Inspect	90
4.12. Starting Motor: Check/Inspect	91
4.13. Water Separator Element: Change	92
4.14. Hydraulic Oil: Change	93
4.15. Hydraulic Pilot Filter: Replace	94
4.16. Transfer Gearbox Oil: Change	95
4.17. Transfer Gearbox: Air Bleeding	96
4.18. Axle Carrier Oil: Change	97
4.19. Axle Hub Oil: Change	98
4.20. Hydraulic System: Venting and Priming	99
4.21. A. Check/Adjust Engine Valve Clearance	100
B. Check/Retight Cylinder Head Bolt	100
4.22. Turbocharger: Check/Clean	101
4.23. Air Conditioner Refrigerant: Check	102
5.0. Shuttle Bus (H12)	103
5.1. Engine Oil: Change	104
5.2. Engine Oil Filter: Replace	105
5.3. Primary Air Filter: Clean and Replace	106
5.4. Engine Fan Belt: Check/Replace	107
5.5. Axle Carrier Oil Level: Check	108
5.6. Axle Hub Oil Level: Check	109
5.7. Fuel Filter: Replace	110

5.8. Air-conditioning System: Check/Clean	111
5.9. Alternator Assembly: Check/Inspect	112
5.10. Starting Motor: Check/Inspect	113
5.11. Water Separator Element: Change	114
5.12. Transfer Gearbox Oil: Change	115
5.13. Transfer Gearbox: Air Bleeding	116
5.14. Axle Carrier Oil: Change	117
5.15. Axle Hub Oil: Change	118
5.16. A. Check/Adjust Engine Valve Clearance	119
B. Check/Retight Cylinder Head Bolt	119
5.17. Turbocharger: Check/Clean	120
5.18. Air Conditioner Refrigerant: Check	121
6.0. Crawler Tractor (L1)	122
6.1. Engine Oil: Change	123
6.2. Engine Oil Filter: Replace	124
6.3. Primary Air Filter: Clean and Replace	125
6.4. Hydraulic Drain Filter: Replace	126
6.5. Engine Fan Belt: Check/Replace	127
6.6. Front Attachments, Cylinders, Pins and Ball Joints: Greasing.....	128
6.7. Fuel Filter: Replace	129
6.8. Controls: Check/Adjust/Lubricate	130
6.9. Air-conditioning System: Check/Clean	131
6.10. Alternator Assembly: Check/Inspect	132
6.11. Starting Motor: Check/Inspect	133
6.12. Water Separator Element: Change	134
6.13. Hydraulic Oil: Change	135
6.14. Hydraulic Pilot Filter: Replace	136
6.15. Transfer Gearbox Oil: Change	137
6.16. Transfer Gearbox: Air Bleeding	138
6.17. Travel Reduction Device Oil: Change	139
6.18. Hydraulic System: Venting and Priming	140
6.19. A. Check/Adjust Engine Valve Clearance	141
B. Check/Retight Cylinder Head Bolt	141
6.20. Turbocharger: Check/Clean	142
6.21. Track Tension: Check/Adjust	143
6.22. Air Conditioner Refrigerant: Check	144
7.0. Front-End Loader (L2)	145
7.1. Engine Oil: Change	146

7.2. Engine Oil Filter: Replace	147
7.3. Primary Air Filter: Clean and Replace	148
7.4. Hydraulic Drain Filter: Replace	149
7.5. Arm and Front Attachments Pins: Greasing	150
7.6. Engine Fan Belt: Check/Replace	151
7.7. Axle Carrier Oil Level: Check	152
7.8. Axle Hub Oil Level: Check	153
7.9. Front Attachments, Cylinders, Pins and Ball Joints: Greasing.....	154
7.10. Fuel Filter: Replace	155
7.11. Controls: Check/Adjust/Lubricate	156
7.12. Air-conditioning System: Check/Clean	157
7.13. Alternator Assembly: Check/Inspect	158
7.14. Starting Motor: Check/Inspect	159
7.15. Water Separator Element: Change	160
7.16. Hydraulic Oil: Change	161
7.17. Hydraulic Pilot Filter: Replace	162
7.18. Transfer Gearbox Oil: Change	163
7.19. Transfer Gearbox: Air Bleeding	164
7.20. Axle Carrier Oil: Change	165
7.21. Axle Hub Oil: Change	166
7.22. Hydraulic System: Venting and Priming	167
7.23. A. Check/Adjust Engine Valve Clearance	168
B. Check/Retight Cylinder Head Bolt	168
7.24. Turbocharger: Check/Clean	169
7.25. Air Conditioner Refrigerant: Check	170
8.0. Road Grader (N1)	171
8.1. Engine Oil: Change	172
8.2. Engine Oil Filter: Replace	173
8.3. Primary Air Filter: Clean and Replace	174
8.4. Hydraulic Drain Filter: Replace	175
8.5. Engine Fan Belt: Check/Replace	176
8.6. Axle Carrier Oil Level: Check	177
8.7. Axle Hub Oil Level: Check	178
8.8. Front Attachments, Cylinders, Pins and Ball Joints: Greasing.....	179
8.9. Fuel Filter: Replace	180
8.10. Controls: Check/Adjust/Lubricate	181
8.11. Air-conditioning System: Check/Clean	182
8.12. Alternator Assembly: Check/Inspect	183
8.13. Starting Motor: Check/Inspect	184

8.14. Water Separator Element: Change	185
8.15. Hydraulic Oil: Change	186
8.16. Hydraulic Pilot Filter: Replace	187
8.17. Transfer Gearbox Oil: Change	188
8.18. Transfer Gearbox: Air Bleeding	189
8.19. Axle Carrier Oil: Change	190
8.20. Axle Hub Oil: Change	191
8.21. Hydraulic System: Venting and Priming	192
8.22. A. Check/Adjust Engine Valve Clearance	193
B. Check/Retight Cylinder Head Bolt	193
8.23. Turbocharger: Check/Clean	194
8.24. Air Conditioner Refrigerant: Check	195
9.0. Vibratory Roller (Z18)	196
9.1. Engine Oil: Change	197
9.2. Engine Oil Filter: Replace	198
9.3. Primary Air Filter: Clean and Replace	199
9.4. Hydraulic Drain Filter: Replace	200
9.5. Engine Fan Belt: Check/Replace	201
9.6. Fuel Filter: Replace	202
9.7. Air-conditioning System: Check/Clean	203
9.8. Alternator Assembly: Check/Inspect	204
9.9. Roller Drum Scraper: Adjust	205
9.10. Roller Tyre Scraper: Adjust	206
9.11. Roller Drum Damping Elements (Vibration): Check	207
9.12. Starting Motor: Check/Inspect	208
9.13. Water Separator Element: Change	209
9.14. Hydraulic Pilot Filter: Replace	210
9.15. Transfer Gearbox Oil: Change	211
9.16. Hydraulic System: Venting and Priming	212
9.17. A. Check/Adjust Engine Valve Clearance	213
B. Check/Retight Cylinder Head Bolt	213
9.18. Turbocharger: Check/Clean	214
9.19. Air Conditioner Refrigerant: Check	215

ACKNOWLEDGEMENT

BIBLIOGRAPHY

NOTES

LEGEND



Visual Inspection-observe safety procedures.



Very Important! Regularly check these items.
Caution: Observe safety procedures at all times.



Report any unusual noise immediately.




1.0. HYDRAULIC CRANE (F4/F5)

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 2

1.1. Engine oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Park the unit on a firm level ground					
1	Open access	1				
2	Put a suitable container under the drain plug at the bottom of the oil pan	2	drain pan	1-pc		
3	Remove the oil filler cap and oil filter	5	oil filter wrench	1-pc		
4	Remove the drain plug to drain the oil into a container Note: While draining, clean the air filter	20	wrench	1-pc		
5	When engine oil drops intermittently, apply compressed air into the filler hole to hasten draining	9			rag	1-pc
6	Install drain plug and oil filter	8			oil filter	1-pc
7	Fill new engine oil into the filler hole with the specified viscosity/SAE No	10			engine oil	as stated
8	Run the engine and check for leaks	5				
	Total	60				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 2



1.2. Engine oil filter: replace

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Replace the oil filter every time the oil is changed Remove the oil filter	3	filter wrench	1-pc		
2	Clean the filter housing base and apply a light coat of engine oil to the gasket of the new filter	2			new oil filter	1-pc
					engine oil	as stated
					rag	1/4 kg
3	Fill the new filter with the specified engine oil	1				
4	Screw on the new filter by hand until the gasket just touches the sealing surface. Tighten the filter a further 1/2 turn	3				
5	Start the engine and check that the gasket is sealed. If not, remove the filter and check the sealing surface	3				
	Note: It is important that the new filter is filled with the prescribed engine oil before it is installed. This is to ensure lubrication of the engine immediately after starting					
	Total	12				

1.0. Hydraulic Crane DPWH Property Code: F4/F5

Maintenance Activity: PM 2

1.3. Primary Air filter: clean and replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Do not, under any circumstances, run the engine without air filter or with a damaged one. The degree of engine wear depends largely on the cleanliness of the induction air.					
1	Open the access door at the rear of the cabin	1				
2	Remove the evacuator valve and air cleaner cover	2				
3	Press with both thumbs on primary filter at the same time as you pull it out. This is to prevent the secondary filter from coming out together with the primary filter.	2				
4	Carefully tap the end of the air filter against a soft and clean surface	5				
5	Use clean and dry compressed air, blow the filter from the inside along the folds	5			compressed air	as stated
6	If there is the smallest hole, scratch, crack or other damage, the filter must be discarded	1			rag	1/4 kg
7	Install the primary air filter and the cover	4				
	Total	20				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 2

1.4. Hydraulic drain filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	5	wrench	1-pc	 rag	1/4 kg
			screw driver	1-pc		
			plier	1-pc		
4	Place a container under the drain filter and turn the filter counter clockwise to remove it.	5			drain pan	1-pc
5	Fill the new filter with oil, thinly coat O-ring with oil.	1			new filter	1-pc
					hydraulic oil	as stated
6	Install the new filter	7				
	Total	20				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 2

1.5. Swing gear bearing: greasing



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Fill grease thru grease nipples at two points using a hand or power grease gun	5	grease gun	1-set	multi-purpose grease	500 gm
					rag	1/4 kg
4	Apply grease to the swing bearing until grease can be seen at the swing bearing seals. Purge old grease with new. Take care not to supply an excessive amount of grease	5				
5	After greasing, clean off the surplus grease completely	3				
	Total	15				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 2

1.6. Arm and Front Attachments Pins: greasing






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Wipe off the grease nipples and the grease gun before greasing, to avoid introducing sand and dirt particles with the grease.					
1	Position the machine on a firm, level ground. Lower the front attachment to the ground and shut down the engine.	2				
2	Press the grease fitting and inject grease with the use of grease gun on the marked points: * Boom cylinder head pin * Boom foot pin * Boom cylinder rod pin * Arm cylinder head pin * Boom arm joint pin * Arm cylinder rod pin * Bucket cylinder head pin	15	grease gun	1-set	multi-purpose grease	500 gm
			wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	After injection, clean off the old grease that has been purged.	3				
	Note: If the machine has been running or working in water the front attachment should be greased on a 10-hour/ daily basis					
	Total	20				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 2

1.7. Engine fan belt: check/replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	<p>Note: A loose fan belt can cause engine overheating, poor charging, and premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing or belt.</p> <p>With the engine shut off, and the starter switch is in the "OFF" position and the controls are tagged, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex approximately 10 mm (0.4 in.)</p>	5	 			
2	To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.	10	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	<p>Replace the belts if it is badly worn, greasy and severely cracked.</p> <p>Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable and if it is frayed or has pieces of material missing.</p>	5				
4	Install the new belts, make sure all pulley must be aligned. The grooves, bearings, shafts are in working order. Brackets are securely clamped. If damaged, replace.	15	 		fan belt	1-pc
5	Repeat activity nos. 1 and 2	15				
	Reminder: Check/adjust the tension of new belts at 50 hours intervals until tension is stabilized and thereafter, every 250 hours.					
	Total	50				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 2

1.8. Axle carrier oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	2				
2	Remove the filling and level checking plug (upper position). If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 2

1.9. Axle Hub oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	2				
2	Position the filling and level checking plug on a horizontal axis (position of 3 o'clock) and remove the plug. If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 3

1.10.Swing drive unit oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Open access. Place a suitable sized container under the drain valve.	1			drain pan	1-pc
4	Open the drain valve.	1	wrench	1-pc	rag	1/4 kg
			plier	1-pc		
5	Drain the oil into the container. Wait until the last drop of oil for few minutes	15				
6	Reinstall the drain plug.	1				
7	Pull out oil dipstick, and fill oil to the correct level thru the oil filler hole.	5			hydraulic oil	as stated
8	Check the oil level again and if necessary, top up. Wait about 5 minutes for checking the level after filling.	5				
	Total	30				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 3

1.11. Swing bath grease: check/change






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Remove the bolts and inspection cover	3	wrench	1-pc		
			screw driver	1-pc		
4	Check the level and condition of the grease. Fill if needed.	10			multi-purpose grease	500 gm
	If the grease is contaminated or discolored with water, remove the lower access cover, then replace the contaminated grease. Install the access cover.				rag	1/4 kg
5	Inspect the seal. Replace if damaged	2			cover seal	1-pc
6	Install the inspection cover and tighten the bolts	3				
	Total	20				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 3

1.12. Fuel filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Exchange filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke.	2			container	1/2 pail
	Locate fuel filter inside engine compartment. Position a small container under the filter.				rag	1/4 kg
2	Unscrew fuel filter from head assembly. Discard fuel filter properly.	3	wrench	1-pc		
			screw driver	1-pc		
3	After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench. Note: Coat fuel filter gasket with fuel and fill fuel filter with clean fuel. This will help reduce fuel system priming.	5	filter wrench	1-pc	new fuel filter	1-pc
					fuel oil	as stated
4	If the fuel filter has been replaced, air may need to be bled using the following <u>FUEL SYSTEM PRIMING</u> : Loosen plug on top of the fuel filter head.	3				
5	Unscrew and pump the hand operated priming pump by the fuel injection pump. Pump priming pump until fuel is present at plug hole in fuel filter head.	5	 			
6	Tighten plug in fuel filter head.	1				
7	Continue to pump the priming pump until a strong resistance is felt. Screw the priming pump knob back into housing to lock the plunger.	3				
8	Start engine and look for signs of leaks. Repeat procedure if necessary.	3				
	Total	25				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 3

1.13. Controls: check/adjust/lubricate






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Controls for: boom; tilting; outrigger					
1	Lubricate all joints and linkages	20	oiler	1-pc	multi-purpose grease	500 gm
			grease gun	1-set	lubricating oil	as stated
			wrench	1-pc	rag	1/4 kg
2	Check and adjust clearance	5				
3	Clean off surplus grease and oil completely.	5				
	Total	30				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 3

1.14. Air-conditioning system: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: When a leak occurs, dirt will accumulate in the area where the leak is.					
1	All service and inspection of air-conditioning system should be performed with the starter switch in the "O" (Off) position.	1				
2	Check the hoses for damage and cracks.	1				
3	Inspect the condenser for dust and debris. Clean if necessary.	2			detergent	as
					water	stated
					rag	1/4 kg
4	Push the "A/C" switch on in order to energize the magnetic clutch. Check the magnetic clutch for dirt and interference.	2				
5	At correct belt tension, it should be possible to depress the belt approximately 10 mm (0.4 in.). Adjust if necessary.	2	wrench 	1-pc		
			screw driver	1-pc		
6	If the unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into the operator's cabin, clean the air-conditioning outer and inner filters.	5				
7	Open the door in the left front of the machine, then remove the cover by loosening the four wing bolts.	5				
8	Remove the outer filter, then the inner filter and inspect for any damage. If the filter is damaged replace with a new one.	2				
9	Use compressed air to clean the filters. If the filter is very dirty, use a mild soap or detergent and water to clean it.	5			compressed air	as stated
10	If water was used, be certain the filters are completely dry. Install the filters and assemble it in reverse order.	5				
	Total	30				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 3

1.15. Alternator assembly: check/inspect





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	2	wrench plier screw driver ampere volt multi-tester	1-pc 1-pc 1-pc 1-set		
3	Pull down the alternator assembly	30				
4	Overhaul and clean	40			multi-purpose grease 1-inch paint brush sand paper rag	250 gm 1-pc 1-pc 1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease, bushing for wear. Replace if necessary.	5				
6	Assemble the alternator and install. If possible, check the alternator ratings on bench testing machine.	30	bench testing machine	1-set		
7	Check the alternator belt tension by pressing downwards on the belt, midway between the fan pulley and alternator pulley.	5				
8	Adjust the belt tension by loosening the alternator adjustment plate bolts. The belt should flex approximately 10 mm (0.4 in.) Retighten the bolts.	5				
9	Run the engine and check for any jarring noise and excessive vibration.	2				
	Total	120				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 3

1.16. Starting motor: check/inspect



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	1	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the starting motor	30				
4	Overhaul and clean	25			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease; bushing for wear. Replace if necessary.	1				
6	Assemble the starting motor and install. If possible, check the starting motor ratings on bench testing machine.	30	bench testing machine	1-set		
9	Run the engine and check for any jarring noise and vibration.	2				
	Total	90				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 3

1.17. Water separator element: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Turn priming pump counterclockwise to unlock the plunger then turn shut-off valve clockwise 90 degrees	1	wrench 	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	Place a suitable sized container under the drain hose	1			drain pan	1-pc
					rag	1/4 kg
3	Open drain valve and drain the fuel from the water separator, afterwards close the drain valve	5				
4	Disconnect sensor connector	1				
5	Remove bowl assembly and set it aside for installation and remove filter element	5	filter wrench	1-pc		
6	Clean the inside surface of the filter head and of the bowl; check the condition of the O-ring. Replace the O-ring if damaged	30				
7	Apply a small amount of fuel to the gasket of the new filter; install the new filter by hand until it contacts the mounting surface. Tighten the filter	30			new filter	1-pc
					fuel oil	as stated
8	Install bowl assembly; reconnect sensor connector	5				
9	Turn shut-off valve counterclockwise 90 degrees	2				
10	Bleed the system	10				
	Total	90				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.18. Hydraulic oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Warning! Take care when changing the oil. Hot oil can cause burns on unprotected skin					
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	3	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc	rag	1/4 kg
4	Open the cover after removing the screws and remove O-ring then pull out the strainer.	20				
6	Place a suitable container under the drain plug of hydraulic tank	1			drain pan	1-pc
7	Remove the drain plug	3				
8	Drain the oil into the container. Wait till the last drop of oil for few minutes	20				
9	Reinstall the drain plug	5				
10	Clean the magnetic rings of strainer thoroughly. Check O-ring and if damaged, replace it with a new one and reinstall the strainer.	5			compressed air	as stated
11	Refill oil and reinstall the cover	20			hydraulic oil	as stated
12	Check the oil in the sight gauge.	1				
13	Perform test run to check for any leaks	10				
	Total	90				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.19. Hydraulic pilot filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	2				
4	Place a container under the pilot filter.	1			drain pan	1-pc
5	Unscrew/remove the filter bowl or canister, O-ring and inner element. Note: The bowl/canister will be filled with oil. Use caution when removing this assembly.	5	wrench	1-pc	rag	1/4 kg
			 plier	1-pc		
6	Install a new inner filter element and O-ring. Apply a small amount of oil around the entire O-ring.	5			pilot filter element	1-pc
					o-ring	1-pc
					hydraulic oil	as stated
7	Reinstall the filter bowl/canister.	2				
8	After changing the pilot filter element, vent air from pump and check level of hydraulic oil tank.	3				
	Total	20				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.20. Transfer gearbox oil: change




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case could eject the oil and plug. Put a suitable sized container , above 3 liters, under the drain plug of transfer gearbox to receive the oil.	15			drain pan	1-pc
4	Loosen the drain plug slowly, discharge the oil completely.	15	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	Tighten the drain plug again and remove the filling plug and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil level is normal. Then install the filling plug.	3			engine oil	as stated
6	Check the oil level once again after a driving time of about 5 minutes. If necessary, refill the oil.	5				
	Total	40				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.21. Transfer gearbox: air bleeding



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	<u>Note:</u> After initial assembly of the machine or disconnecting high/low speed pressure line (from pump to transfer gearbox) and remounting, bleed the air from the transfer gearbox before travelling the machine. Releaser the parking brake.	15				
4	Set the gear speed change lever to 2nd. Open bleeder of the brake and bleed it for approximately 20 seconds.	3	wrench screw driver	1-pc 1-pc	rag	1/4 kg
5	When the brake is bled the first time, additionally open also bleeder of the emergency actuating device to bring it into its initial position. In this case no oil flows out.	3				
6	Close both bleeders.	1				
7	Set the gear speed change lever to 1st (low speed). Open bleeder of the clutch and bleed it for approximately 20 seconds.	2				
8	Close bleeder of the clutch.	1				
9	Repeat bleeding the brake and clutch 2 times each for approximately 20 seconds. At the last bleeding procedure no air bubbles are allowed to be visible in the oil anymore.	10				
10	Check all screws connections for leaks. <u>Important:</u> If the air in the transfer gearbox is not vented out, a serious fault may develop, such as damage of the clutch in the transfer gearbox may occur.	3				
	Total	40				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.22. Travel reduction device oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Note: Drain and replace the oil after the first 250 hours of operation and 1000 hours thereafter. Rotate the track until the three (3) ports are in their proper positions., That is, Port 1 is the level plug, Port 2 is the drain plug and Port 3 is the fill plug.	3				
4	Place a container under the drain plug and remove the plugs (1 to 3), to drain the travel reduction gear oil.	5	wrench	1-pc	drain pan	1-pc
					rag	1/4 kg
5	Install the drain plug. Refill the travel reduction gear case with fluid thru the fill port until the fluid level is at level port. Install the level plug and fill plug.	5			gear oil	as stated
	Total	15				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.23. Axle Carrier oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	5				
2	Put a suitable container under the drain plug (lower position) of axle carrier to receive the oil.	2			drain pan	1-pc
3	Loosen the drain plug, then the filling plug (upper position) and discharge the oil completely.	5	wrench	1-pc	rag	1/4 kg
4	Tighten the drain plug and supply new oil thru the filling plug. If the oil is about to overflow from the hole, the oil level is normal.	5			gear oil	as stated
5	Install the filling plug and tighten securely.	3				
	Total	20				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.24. Axle Hub oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	5				
2	Put a suitable sized container under the drain plug of axle carrier to receive the oil.	1			drain pan	1-pc
					rag	1/4 kg
3	Position the drain plug on the vertical axis (position of 6 o'clock).	1				
4	Loosen the drain plug and filling plug to discharge the oil completely.	5	wrench	1-pc	gear oil	as stated
5	Tighten the drain plug again and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil is normal.	5				
6	Install filling plug and tighten securely.	3				
	Total	20				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.25. Hydraulic System: venting and priming

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: If pump is run without sufficient oil in the main hydraulic pump, damage can occur. Always vent pump of air after draining hydraulic system. With the engine stopped, remove vent plug to see if any oil is present.	3	wrench 	1-pc	rag	1/4 kg
2	If oil is not present, fill pump with oil thru port.	5			hydraulic oil	as stated
3	Install vent plug first.	2				
4	Start engine and run it for several minutes at low idle engine speed. This will pressurize the hydraulic oil tank and system.	5	 			
5	Slowly loosen vent plug several turns, until hydraulic oil flows out of plug. This shows that air has been released. Tighten the plug.	5				
	Total	20				




1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.26. A. Check/adjust engine valve clearance

B. Check/retight cylinder head bolt





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Open access	1				
2	Remove parts/accessories to give way for the adjustment of engine valve	5	flat screw driver	1-pc		
			cross screw driver	1-pc		
			plier	1-pc		
			combination wrench	1-pc		
3	Remove valve cover	5			rag	1/4 kg
4	Check/untorque cylinder head bolt	15				
5	Adjust valve clearance	30	feeler gauge	1-set		
6	After valve clearance adjustment, repeat the procedure in reverse order	25			sealant	1-tube
					gasket	1-set
7	Start the engine and check for leak and any distorting noise	5				
	Note: Follow procedure of engine valve clearance/adjustment according to manufacturer's guide and standards					
	Total	86				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.27. Turbocharger: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Leave the engine running at low idling speed for at least a minute after start and a few minutes before it is stopped. This is to safeguard the lubrication of the turbocharger.					
1	Remove the oil filler pipe and drain pipe, then remove the intake air pipe connector and blower housing so that the blower impeller can be seen.	10	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	NOTE: excessive carbon or oil sludge adhering to turbocharger blower may lead to performance deterioration and possible damage. Using light oil as a cleaning agent, remove the carbon, sludge, and other dirt from the blower impeller.	5			light oil	as stated
					rag	1/4 kg
3	Pour in light oil thru the turbocharger oil filler and rotate the blower impeller several times to wash out the sludge.	5				
4	Rotate the impeller by hand at least one turn at speed to check that there is contact noise or catching inside. If the impeller does not turn smoothly, contact the equipment manufacturer for repair or replacement.	10				
5	If there is no abnormality, dry off the light oil with compressed air after inspection, then add engine oil.	5			compressed air	as stated
6	Reassemble in reverse order.	20				
7	Run the engine and if any jarring noises be heard and shows unusual vibration, it must be reconditioned or changed immediately.	5	 			
	Total	60				

1.0. Hydraulic Crane

DPWH Property Code: F4/F5

Maintenance Activity: PM 4



1.28. Track tension: check/adjust

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	<p>Note: The track adjusting mechanism is under very high-pressure. Never release pressure too suddenly. The track tension grease valve should never be backed off more than one (1) complete turn from the tightened down position</p> <p>Under normal usage, the track shoe link pins and bushing wear- out and reducing the track tension</p>					
1	Track tension is checked by jacking up one side of the truck side. Place blocking under frame while taking measurement. Turn the track backward 1-2 turns	10	wrench	1-set		
			mechanical jack	1-set		
			jack-up stand	1-set		
2	Clean off the tracks before checking the clearance. Measurement can be inaccurate if there is too much mud or dirt or other material in the track assembly	10				
3	Measuring the distance between the bottom of the side frame and the top of the lowest crawler shoe. Recommended tension for operation over most types of terrain is 290 - 310 mm (11.42 - 12.20 inches)	5	tape measure	1-set		
4	Track tension adjustments are made thru the grease fitting located in the middle of each side frame. Adding grease increases the length of an adjustment cylinder. The longer the adjustment cylinder, the greater the pressure on the tension spring pushing the track idler wheel outward.	15	grease gun	1-set	multi-purpose grease	500 gm
					rag	1/4 kg
5	If there is not enough slack or clearance in the tracks and the adjustment is too tight, the idler wheel and adjusting cylinder can be retracted by bleeding off grease thru hole in valve by loosening valve slowly. When grease starts to leak out, stop loosening it.	15	 			
6	After track is adjusted by loosening valve, be sure to tighten valve to 14 kg.m or 101 ft. lb.	5				
	Total	60				

1.0. Hydraulic Crane DPWH Property Code: F4/F5

Maintenance Activity: PM 4

1.29. Air conditioner refrigerant: check

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Note: Inhaling air conditioner refrigerant gas thru a lit cigarette or other smoking method or inhaling fumes released from a flame contacting refrigerant gas can cause bodily harm or death					
1	Run engine at about 1,800 rpm. Operate for a minimum of ten (10) minutes to stabilize the air conditioning system	10				
2	Press the "HI" fan speed switch to set maximum airflow	1				
	Put the temperature control switch in maximum cooling position					
	Press the "Internal Air Circulation switch					
3	Compare the flow of bubbles in the sight glass of receiver dryer in the following table:	1				
4	Amount of refrigerant: Almost clear. Any bubbles disappear. Normal; No bubbles are seen. High. Withdraw the system with the correct amount of HFC 134a A flow of bubbles is visible. Low. Charge the system with the correct amount of HFC 134a	8			rag	1/4 kg
	Important: Overfilling refrigerant can cause dangerous high-pressure and poor cooling action; and low refrigerant level can cause compressor damage					
	Total	20				




2.0. HYDRAULIC EXCAVATOR (F16/F17)

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 2

2.1. Engine oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Park the unit on a firm level ground					
1	Open access	1				
2	Put a suitable container under the drain plug at the bottom of the oil pan	2	drain pan	1-pc		
3	Remove the oil filler cap and oil filter	5	oil filter wrench	1-pc		
4	Remove the drain plug to drain the oil into a container Note: While draining, clean the air filter	20	wrench	1-pc		
5	When engine oil drops intermittently, apply compressed air into the filler hole to hasten draining	9			rag	1-pc
6	Install drain plug and oil filter	8			oil filter	1-pc
7	Fill new engine oil into the filler hole with the specified viscosity/SAE No	10			engine oil	as stated
8	Run the engine and check for leaks	5				
	Total	60				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 2

2.2. Engine oil filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Replace the oil filter every time the oil is changed Remove the oil filter	3	filter wrench	1-pc		
2	Clean the filter housing base and apply a light coat of engine oil to the gasket of the new filter	2			new oil filter	1-pc
					engine oil	as stated
					rag	1/4 kg
3	Fill the new filter with the specified engine oil	1				
4	Screw on the new filter by hand until the gasket just touches the sealing surface. Tighten the filter a further 1/2 turn	3				
5	Start the engine and check that the gasket is sealed. If not, remove the filter and check the sealing surface	3				
	Note: It is important that the new filter is filled with the prescribed engine oil before it is installed. This is to ensure lubrication of the engine immediately after starting					
	Total	12				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 2

2.3. Primary Air filter: clean and replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Do not, under any circumstances, run the engine without air filter or with a damaged one. The degree of engine wear depends largely on the cleanliness of the induction air.					
1	Open the access door at the rear of the cabin	1				
2	Remove the evacuator valve and air cleaner cover	2				
3	Press with both thumbs on primary filter at the same time as you pull it out. This is to prevent the secondary filter from coming out together with the primary filter.	2				
4	Carefully tap the end of the air filter against a soft and clean surface	5				
5	Use clean and dry compressed air, blow the filter from the inside along the folds	5			compressed air	as stated
6	If there is the smallest hole, scratch, crack or other damage, the filter must be discarded	1			rag	1/4 kg
7	Install the primary air filter and the cover	4				
	Total	20				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 2

2.4. Hydraulic drain filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	5	wrench	1-pc	 rag	1/4 kg
			screw driver	1-pc		
			plier	1-pc		
4	Place a container under the drain filter and turn the filter counter clockwise to remove it.	5			drain pan	1-pc
5	Fill the new filter with oil, thinly coat O-ring with oil.	1			new filter	1-pc
					hydraulic oil	as stated
6	Install the new filter	7				
	Total	20				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 2

2.5. Swing gear bearing: greasing



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Fill grease thru grease nipples at two points using a hand or power grease gun	5	grease gun	1-set	multi-purpose grease	500 gm
					rag	1/4 kg
4	Apply grease to the swing bearing until grease can be seen at the swing bearing seals. Purge old grease with new. Take care not to supply an excessive amount of grease	5				
5	After greasing, clean off the surplus grease completely	3				
	Total	15				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 2

2.6. Arm and Front Attachments Pins: greasing






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Wipe off the grease nipples and the grease gun before greasing, to avoid introducing sand and dirt particles with the grease.					
1	Position the machine on a firm, level ground. Lower the front attachment to the ground and shut down the engine.	2				
2	Press the grease fitting and inject grease with the use of grease gun on the marked points: • Boom cylinder head pin • Boom foot pin • Boom cylinder rod pin • Arm cylinder head pin • Boom arm joint pin • Arm cylinder rod pin • Breaker cylinder head pin	15	grease gun	1-set	multi-purpose grease	500 gm
			wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	After injection, clean off the old grease that has been purged.	3				
	Note: If the machine has been running or working in water the front attachment should be greased on a 10-hour/ daily basis					
	Total	20				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 2

2.7. Engine fan belt: check/replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	<p>Note: A loose fan belt can cause engine overheating, poor charging, and premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing or belt.</p> <p>With the engine shut off, and the starter switch is in the "OFF" position and the controls are tagged, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex approximately 10 mm (0.4 in.)</p>	5	 			
2	To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.	10	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	<p>Replace the belts if it is badly worn, greasy and severely cracked.</p> <p>Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable and if it is frayed or has pieces of material missing.</p>	5				
4	Install the new belts, make sure all pulley must be aligned. The grooves, bearings, shafts are in working order. Brackets are securely clamped. If damaged, replace.	15	 		fan belt	1-pc
5	Repeat activity nos. 1 and 2	15				
	Reminder: Check/adjust the tension of new belts at 50 hours intervals until tension is stabilized and thereafter, every 250 hours.					
	Total	50				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 2

2.8. Axle carrier oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	2				
2	Remove the filling and level checking plug (upper position). If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 2

2.9. Axle Hub oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	2				
2	Position the filling and level checking plug on a horizontal axis (position of 3 o'clock) and remove the plug. If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 3

2.10. Swing drive unit oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Open access. Place a suitable sized container under the drain valve.	1			drain pan	1-pc
4	Open the drain valve.	1	wrench	1-pc	rag	1/4 kg
			plier	1-pc		
5	Drain the oil into the container. Wait until the last drop of oil for few minutes	15				
6	Reinstall the drain plug.	1				
7	Pull out oil dipstick, and fill oil to the correct level thru the oil filler hole.	5			hydraulic oil	as stated
8	Check the oil level again and if necessary, top up. Wait about 5 minutes for checking the level after filling.	5				
	Total	30				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 3

2.11. Swing bath grease: check/change






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Remove the bolts and inspection cover	3	wrench	1-pc		
			screw driver	1-pc		
4	Check the level and condition of the grease. Fill if needed.	10			multi-purpose grease	500 gm
	If the grease is contaminated or discolored with water, remove the lower access cover, then replace the contaminated grease. Install the access cover.				rag	1/4 kg
5	Inspect the seal. Replace if damaged	2			cover seal	1-pc
6	Install the inspection cover and tighten the bolts	3				
	Total	20				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 3

2.12. Fuel filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Exchange filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke.	2			container	1/2 pail
	Locate fuel filter inside engine compartment. Position a small container under the filter.				rag	1/4 kg
2	Unscrew fuel filter from head assembly. Discard fuel filter properly.	3	wrench	1-pc		
			screw driver	1-pc		
3	After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench. Note: Coat fuel filter gasket with fuel and fill fuel filter with clean fuel. This will help reduce fuel system priming.	5	filter wrench	1-pc	new fuel filter	1-pc
					fuel oil	as stated
4	If the fuel filter has been replaced, air may need to be bleed using the following <u>FUEL SYSTEM PRIMING</u> : Loosen plug on top of the fuel filter head.	3				
5	Unscrew and pump the hand operated priming pump by the fuel injection pump. Pump priming pump until fuel is present at plug hole in fuel filter head.	5	 			
6	Tighten plug in fuel filter head.	1				
7	Continue to pump the priming pump until a strong resistance is felt. Screw the priming pump knob back into housing to lock the plunger.	3				
8	Start engine and look for signs of leaks. Repeat procedure if necessary.	3				
	Total	25				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 3

2.13. Controls: check/adjust/lubricate






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Controls for: bucket; tilting; tandem;					
1	lubricate all joints and linkages	20	oiler	1-pc	multi-purpose grease	500 gm
			grease gun	1-set	lubricating oil	as stated
			wrench	1-pc	rag	1/4 kg
2	Check and adjust clearance	5				
3	Clean off surplus grease and oil completely.	5				
	Total	30				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 3

2.14. Air-conditioning system: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: When a leak occurs, dirt will accumulate in the area where the leak is.					
1	All service and inspection of air-conditioning system should be performed with the starter switch in the "O" (Off) position.	1				
2	Check the hoses for damage and cracks.	1				
3	Inspect the condenser for dust and debris. Clean if necessary.	2			detergent	as stated
					water	
					rag	1/4 kg
4	Push the "A/C" switch on in order to energize the magnetic clutch. Check the magnetic clutch for dirt and interference.	2				
5	At correct belt tension, it should be possible to depress the belt approximately 10 mm (0.4 in.). Adjust if necessary.	2	wrench	1-pc		
			 screw driver	1-pc		
6	If the unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into the operator's cabin, clean the air-conditioning outer and inner filters.	5				
7	Open the door in the left front of the machine, then remove the cover by loosening the four wing bolts.	5				
8	Remove the outer filter, then the inner filter and inspect for any damage. If the filter is damaged replace with a new one.	2				
9	Use compressed air to clean the filters. If the filter is very dirty, use a mild soap or detergent and water to clean it.	5			compressed air	as stated
10	If water was used, be certain the filters are completely dry. Install the filters and assemble it in reverse order.	5				
	Total	30				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 3

2.15. Alternator assembly: check/inspect





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	2	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the alternator assembly	30				
4	Overhaul and clean	40			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease, bushing for wear. Replace if necessary.	5				
6	Assemble the alternator and install. If possible, check the alternator ratings on bench testing machine.	30	bench testing machine	1-set		
7	Check the alternator belt tension by pressing downwards on the belt, midway between the fan pulley and alternator pulley.	5				
8	Adjust the belt tension by loosening the alternator adjustment plate bolts. The belt should flex approximately 10 mm (0.4 in.) Retighten the bolts.	5				
9	Run the engine and check for any jarring noise and excessive vibration.	2				
	Total	120				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 3

2.16. Starting motor: check/inspect




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	1	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the starting motor	30				
4	Overhaul and clean	25			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease; bushing for wear. Replace if necessary.	1				
6	Assemble the starting motor and install. If possible, check the starting motor ratings on bench testing machine.	30	bench testing machine	1-set		
9	Run the engine and check for any jarring noise and vibration.	2				
	Total	90				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 3

2.17. Water separator element: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Turn priming pump counterclockwise to unlock the plunger then turn shut-off valve clockwise 90 degrees	1	 wrench	1-pc		
			 screw driver	1-pc		
			plier	1-pc		
2	Place a suitable sized container under the drain hose	1			drain pan	1-pc
					rag	1/4 kg
3	Open drain valve and drain the fuel from the water separator, afterwards close the drain valve	5				
4	Disconnect sensor connector	1				
5	Remove bowl assembly and set it aside for installation and remove filter element	5	filter wrench	1-pc		
6	Clean the inside surface of the filter head and of the bowl; check the condition of the O-ring. Replace the O-ring if damaged	30				
7	Apply a small amount of fuel to the gasket of the new filter; install the new filter by hand until it contacts the mounting surface. Tighten the filter	30			new filter	1-pc
					fuel oil	as stated
8	Install bowl assembly; reconnect sensor connector	5				
9	Turn shut-off valve counterclockwise 90 degrees	2				
10	Bleed the system	10				
	Total	90				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.18. Hydraulic oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Warning! Take care when changing the oil. Hot oil can cause burns on unprotected skin					
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	3	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc	rag	1/4 kg
4	Open the cover after removing the screws and remove O-ring then pull out the strainer.	20				
6	Place a suitable container under the drain plug of hydraulic tank	1			drain pan	1-pc
7	Remove the drain plug	3				
8	Drain the oil into the container. Wait till the last drop of oil for few minutes	20				
9	Reinstall the drain plug	5				
10	Clean the magnetic rings of strainer thoroughly. Check O-ring and if damaged, replace it with a new one and reinstall the strainer.	5			compressed air	as stated
11	Refill oil and reinstall the cover	20			hydraulic oil	as stated
12	Check the oil in the sight gauge.	1				
13	Perform test run to check for any leaks	10				
	Total	90				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.19. Hydraulic pilot filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	2				
4	Place a container under the pilot filter.	1			drain pan	1-pc
5	Unscrew/remove the filter bowl or canister, O-ring and inner element. Note: The bowl/canister will be filled with oil. Use caution when removing this assembly.	5	wrench	1-pc	rag	1/4 kg
			 plier	1-pc		
6	Install a new inner filter element and O-ring. Apply a small amount of oil around the entire O-ring.	5			pilot filter element	1-pc
					o-ring	1-pc
					hydraulic oil	as stated
7	Reinstall the filter bowl/canister.	2				
8	After changing the pilot filter element, vent air from pump and check level of hydraulic oil tank.	3				
	Total	20				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.20. Transfer gearbox oil: change




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case could eject the oil and plug. Put a suitable sized container , above 3 liters, under the drain plug of transfer gearbox to receive the oil.	15			drain pan	1-pc
4	Loosen the drain plug slowly, discharge the oil completely.	15	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	Tighten the drain plug again and remove the filling plug and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil level is normal. Then install the filling plug.	3			engine oil	as stated
6	Check the oil level once again after a driving time of about 5 minutes. If necessary, refill the oil.	5				
	Total	40				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.21. Transfer gearbox: air bleeding



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	<u>Note:</u> After initial assembly of the machine or disconnecting high/low speed pressure line (from pump to transfer gearbox) and remounting, bleed the air from the transfer gearbox before travelling the machine. Releaser the parking brake.	15				
4	Set the gear speed change lever to 2nd. Open bleeder of the brake and bleed it for approximately 20 seconds.	3	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	When the brake is bled the first time, additionally open also bleeder of the emergency actuating device to bring it into its initial position. In this case no oil flows out.	3				
6	Close both bleeders.	1				
7	Set the gear speed change lever to 1st (low speed). Open bleeder of the clutch and bleed it for approximately 20 seconds.	2				
8	Close bleeder of the clutch.	1				
9	Repeat bleeding the brake and clutch 2 times each for approximately 20 seconds. At the last bleeding procedure no air bubbles are allowed to be visible in the oil anymore.	10				
10	Check all screws connections for leaks. <u>Important:</u> If the air in the transfer gearbox is not vented out, a serious fault may develop, such as damage of the clutch in the transfer gearbox may occur.	3				
	Total	40				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.22. Travel reduction device oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Note: Drain and replace the oil after the first 250 hours of operation and 1000 hours thereafter. Rotate the track until the three (3) ports are in their proper positions., That is, Port 1 is the level plug, Port 2 is the drain plug and Port 3 is the fill plug.	3				
4	Place a container under the drain plug and remove the plugs (1 to 3), to drain the travel reduction gear oil.	5	wrench	1-pc	drain pan	1-pc
					rag	1/4 kg
5	Install the drain plug. Refill the travel reduction gear case with fluid thru the fill port until the fluid level is at level port. Install the level plug and fill plug.	5			gear oil	as stated
	Total	15				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.23. Axle Carrier oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	5				
2	Put a suitable container under the drain plug (lower position) of axle carrier to receive the oil.	2			drain pan	1-pc
3	Loosen the drain plug, then the filling plug (upper position) and discharge the oil completely.	5	wrench	1-pc	rag	1/4 kg
4	Tighten the drain plug and supply new oil thru the filling plug. If the oil is about to overflow from the hole, the oil level is normal.	5			gear oil	as stated
5	Install the filling plug and tighten securely.	3				
	Total	20				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.24. Axle Hub oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	5				
2	Put a suitable sized container under the drain plug of axle carrier to receive the oil.	1			drain pan	1-pc
					rag	1/4 kg
3	Position the drain plug on the vertical axis (position of 6 o'clock).	1				
4	Loosen the drain plug and filling plug to discharge the oil completely.	5	wrench	1-pc	gear oil	as stated
5	Tighten the drain plug again and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil is normal.	5				
6	Install filling plug and tighten securely.	3				
	Total	20				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.25. Hydraulic System: venting and priming

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: If pump is run without sufficient oil in the main hydraulic pump, damage can occur. Always vent pump of air after draining hydraulic system. With the engine stopped, remove vent plug to see if any oil is present.	3	wrench 	1-pc	rag	1/4 kg
2	If oil is not present, fill pump with oil thru port.	5			hydraulic oil	as stated
3	Install vent plug first.	2				
4	Start engine and run it for several minutes at low idle engine speed. This will pressurize the hydraulic oil tank and system.	5	 			
5	Slowly loosen vent plug several turns, until hydraulic oil flows out of plug. This shows that air has been released. Tighten the plug.	5				
	Total	20				



2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.26. A. Check/adjust engine valve clearance

B. Check/retight cylinder head bolt






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Open access	1				
2	Remove parts/accessories to give way for the adjustment of engine valve	5	flat screw driver	1-pc		
			cross screw driver	1-pc		
			plier	1-pc		
			combination wrench	1-pc		
3	Remove valve cover	5			rag	1/4 kg
4	Check/untorque cylinder head bolt	15				
5	Adjust valve clearance	30	feeler gauge	1-set		
6	After valve clearance adjustment, repeat the procedure in reverse order	25			sealant	1-tube
					gasket	1-set
7	Start the engine and check for leak and any distorting noise	5				
	Note: Follow procedure of engine valve clearance/adjustment according to manufacturer's guide and standards					
	Total	86				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.27. Turbocharger: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Leave the engine running at low idling speed for at least a minute after start and a few minutes before it is stopped. This is to safeguard the lubrication of the turbocharger.					
1	Remove the oil filler pipe and drain pipe, then remove the intake air pipe connector and blower housing so that the blower impeller can be seen.	10	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	NOTE: excessive carbon or oil sludge adhering to turbocharger blower may lead to performance deterioration and possible damage. Using light oil as a cleaning agent, remove the carbon, sludge, and other dirt from the blower impeller.	5			light oil	as stated
					rag	1/4 kg
3	Pour in light oil thru the turbocharger oil filler and rotate the blower impeller several times to wash out the sludge.	5				
4	Rotate the impeller by hand at least one turn at speed to check that there is contact noise or catching inside. If the impeller does not turn smoothly, contact the equipment manufacturer for repair or replacement.	10				
5	If there is no abnormality, dry off the light oil with compressed air after inspection, then add engine oil.	5			compressed air	as stated
6	Reassemble in reverse order.	20				
7	Run the engine and if any jarring noises be heard and shows unusual vibration, it must be reconditioned or changed immediately.	5				
						
	Total	60				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.28. Track tension: check/adjust



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	<p>Note: The track adjusting mechanism is under very high-pressure. Never release pressure too suddenly. The track tension grease valve should never be backed off more than one (1) complete turn from the tightened down position</p> <p>Under normal usage, the track shoe link pins and bushing wear- out and reducing the track tension</p>					
1	Track tension is checked by jacking up one side of the excavator. Place blocking under frame while taking measurement. Turn the track backward 1-2 turns	10	wrench	1-set		
			mechanical jack	1-set		
			jack-up stand	1-set		
2	Clean off the tracks before checking the clearance. Measurement can be inaccurate if there is too much mud or dirt or other material in the track assembly	10				
3	Measuring the distance between the bottom of the side frame and the top of the lowest crawler shoe. Recommended tension for operation over most types of terrain is 290 - 310 mm (11.42 - 12.20 inches)	5	tape measure	1-set		
4	Track tension adjustments are made thru the grease fitting located in the middle of each side frame. Adding grease increases the length of an adjustment cylinder. The longer the adjustment cylinder, the greater the pressure on the tension spring pushing the track idler wheel outward.	15	grease gun	1-set	multi-purpose grease	500 gm
					rag	1/4 kg
5	If there is not enough slack or clearance in the tracks and the adjustment is too tight, the idler wheel and adjusting cylinder can be retracted by bleeding off grease thru hole in valve by loosening valve slowly. When grease starts to leak out, stop loosening it.	15	 			
6	After track is adjusted by loosening valve, be sure to tighten valve to 14 kg.m or 101 ft. lb.	5				
	Total	60				

2.0. Hydraulic Excavator

DPWH Property Code: F16/F17

Maintenance Activity: PM 4

2.29. Air conditioner refrigerant: check

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Note: Inhaling air conditioner refrigerant gas thru a lit cigarette or other smoking method or inhaling fumes released from a flame contacting refrigerant gas can cause bodily harm or death					
1	Run engine at about 1,800 rpm. Operate for a minimum of ten (10) minutes to stabilize the air conditioning system	10				
2	Press the "HI" fan speed switch to set maximum airflow	1				
	Put the temperature control switch in maximum cooling position					
	Press the "Internal Air Circulation switch					
3	Compare the flow of bubbles in the sight glass of receiver dryer in the following table:	1				
4	Amount of refrigerant: Almost clear. Any bubbles disappear. Normal; No bubbles are seen. High. Withdraw the system with the correct amount of HFC 134a A flow of bubbles is visible. Low. Charge the system with the correct amount of HFC 134a	8			rag	1/4 kg
	Important: Overfilling refrigerant can cause dangerous high-pressure and poor cooling action; and low refrigerant level can cause compressor damage					
	Total	20				




3.0. SERVICE VEHICLE (H1)

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 2

3.1. Engine oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Park the unit on a firm level ground					
1	Open access	1				
2	Put a suitable container under the drain plug at the bottom of the oil pan	2	drain pan	1-pc		
3	Remove the oil filler cap and oil filter	5	oil filter wrench	1-pc		
4	Remove the drain plug to drain the oil into a container Note: While draining, clean the air filter	20	wrench	1-pc		
5	When engine oil drops intermittently, apply compressed air into the filler hole to hasten draining	9			rag	1-pc
6	Install drain plug and oil filter	8			oil filter	1-pc
7	Fill new engine oil into the filler hole with the specified viscosity/SAE No	10			engine oil	as stated
8	Run the engine and check for leaks	5				
	Total	60				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 2

3.2. Engine oil filter: replace






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Replace the oil filter every time the oil is changed Remove the oil filter	3	filter wrench	1-pc		
2	Clean the filter housing base and apply a light coat of engine oil to the gasket of the new filter	2			new oil filter	1-pc
					engine oil	as stated
					rag	1/4 kg
3	Fill the new filter with the specified engine oil	1				
4	Screw on the new filter by hand until the gasket just touches the sealing surface. Tighten the filter a further 1/2 turn	3				
5	Start the engine and check that the gasket is sealed. If not, remove the filter and check the sealing surface	3				
	Note: It is important that the new filter is filled with the prescribed engine oil before it is installed. This is to ensure lubrication of the engine immediately after starting					
	Total	12				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 2

3.3. Engine fan belt: check/replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	<p>Note: A loose fan belt can cause engine overheating, poor charging, and premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing or belt.</p> <p>With the engine shut off, and the starter switch is in the "OFF" position and the controls are tagged, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex approximately 10 mm (0.4 in.)</p>	5	 			
2	To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.	10	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	<p>Replace the belts if it is badly worn, greasy and severely cracked.</p> <p>Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable and if it is frayed or has pieces of material missing.</p>	5				
4	Install the new belts, make sure all pulley must be aligned. The grooves, bearings, shafts are in working order. Brackets are securely clamped. If damaged, replace.	15	 		fan belt	1-pc
5	Repeat activity nos. 1 and 2	15				
	Reminder: Check/adjust the tension of new belts at 50 hours intervals until tension is stabilized and thereafter, every 250 hours.					
	Total	50				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 2

3.4. Axle carrier oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	2				
2	Remove the filling and level checking plug (upper position). If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 2

3.5. Axle Hub oil level: check






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	2				
2	Position the filling and level checking plug on a horizontal axis (position of 3 o'clock) and remove the plug. If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 3

3.6. Fuel filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Exchange filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke. Locate fuel filter inside engine compartment. Position a small container under the filter.	2			container	1/2 pail
					rag	1/4 kg
2	Unscrew fuel filter from head assembly. Discard fuel filter properly.	3	wrench	1-pc		
			screw driver	1-pc		
3	After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench. Note: Coat fuel filter gasket with fuel and fill fuel filter with clean fuel. This will help reduce fuel system priming.	5	filter wrench	1-pc	new fuel filter	1-pc
					fuel oil	as stated
4	If the fuel filter has been replaced, air may need to be bleed using the following <u>FUEL SYSTEM PRIMING</u> : Loosen plug on top of the fuel filter head.	3				
5	Unscrew and pump the hand operated priming pump by the fuel injection pump. Pump priming pump until fuel is present at plug hole in fuel filter head.	5	 			
6	Tighten plug in fuel filter head.	1				
7	Continue to pump the priming pump until a strong resistance is felt. Screw the priming pump knob back into housing to lock the plunger.	3				
8	Start engine and look for signs of leaks. Repeat procedure if necessary.	3				
	Total	25				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 3

3.7. Controls: check/adjust/lubricate






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Controls for: bucket; tilting; tandem;					
1	Lubricate all joints and linkages	20	oiler	1-pc	multi-purpose grease	500 gm
			grease gun	1-set	lubricating oil	as stated
			wrench	1-pc	rag	1/4 kg
2	Check and adjust clearance	5				
3	Clean off surplus grease and oil completely.	5				
	Total	30				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 3

3.8. Air-conditioning system: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: When a leak occurs, dirt will accumulate in the area where the leak is.					
1	All service and inspection of air-conditioning system should be performed with the starter switch in the "O" (Off) position.	1				
2	Check the hoses for damage and cracks.	1				
3	Inspect the condenser for dust and debris. Clean if necessary.	2			detergent	as stated
					water	
					rag	1/4 kg
4	Push the "A/C" switch on in order to energize the magnetic clutch. Check the magnetic clutch for dirt and interference.	2				
5	At correct belt tension, it should be possible to depress the belt approximately 10 mm (0.4 in.). Adjust if necessary.	2	wrench 	1-pc		
			screw driver	1-pc		
6	If the unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into the operator's cabin, clean the air-conditioning outer and inner filters.	5				
7	Open the door in the left front of the machine, then remove the cover by loosening the four wing bolts.	5				
8	Remove the outer filter, then the inner filter and inspect for any damage. If the filter is damaged replace with a new one.	2				
9	Use compressed air to clean the filters. If the filter is very dirty, use a mild soap or detergent and water to clean it.	5			compressed air	as stated
10	If water was used, be certain the filters are completely dry. Install the filters and assemble it in reverse order.	5				
	Total	30				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 3

3.9. Alternator assembly: check/inspect





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	2	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the alternator assembly	30				
4	Overhaul and clean	40			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease, bushing for wear. Replace if necessary.	5				
6	Assemble the alternator and install. If possible, check the alternator ratings on bench testing machine.	30	bench testing machine	1-set		
7	Check the alternator belt tension by pressing downwards on the belt, midway between the fan pulley and alternator pulley.	5				
8	Adjust the belt tension by loosening the alternator adjustment plate bolts. The belt should flex approximately 10 mm (0.4 in.) Retighten the bolts.	5				
9	Run the engine and check for any jarring noise and excessive vibration.	2				
	Total	120				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 3

3.10. Starting motor: check/inspect



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	1	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the starting motor	30				
4	Overhaul and clean	25			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease; bushing for wear. Replace if necessary.	1				
6	Assemble the starting motor and install. If possible, check the starting motor ratings on bench testing machine.	30	bench testing machine	1-set		
9	Run the engine and check for any jarring noise and vibration.	2				
	Total	90				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 4

3.11. Transfer gearbox oil: change




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case could eject the oil and plug. Put a suitable sized container , above 3 liters, under the drain plug of transfer gearbox to receive the oil.	15			drain pan	1-pc
4	Loosen the drain plug slowly, discharge the oil completely.	15	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	Tighten the drain plug again and remove the filling plug and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil level is normal. Then install the filling plug.	3			engine oil	as stated
6	Check the oil level once again after a driving time of about 5 minutes. If necessary, refill the oil.	5				
	Total	40				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 4

3.12. Transfer gearbox: air bleeding



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	<u>Note:</u> After initial assembly of the machine or disconnecting high/low speed pressure line (from pump to transfer gearbox) and remounting, bleed the air from the transfer gearbox before travelling the machine. Releaser the parking brake.	15				
4	Set the gear speed change lever to 2nd. Open bleeder of the brake and bleed it for approximately 20 seconds.	3	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	When the brake is bled the first time, additionally open also bleeder of the emergency actuating device to bring it into its initial position. In this case no oil flows out.	3				
6	Close both bleeders.	1				
7	Set the gear speed change lever to 1st (low speed). Open bleeder of the clutch and bleed it for approximately 20 seconds.	2				
8	Close bleeder of the clutch.	1				
9	Repeat bleeding the brake and clutch 2 times each for approximately 20 seconds. At the last bleeding procedure no air bubbles are allowed to be visible in the oil anymore.	10				
10	Check all screws connections for leaks. <u>Important:</u> If the air in the transfer gearbox is not vented out, a serious fault may develop, such as damage of the clutch in the transfer gearbox may occur.	3				
	Total	40				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 4

3.13. Axle Carrier oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	5				
2	Put a suitable container under the drain plug (lower position) of axle carrier to receive the oil.	2			drain pan	1-pc
3	Loosen the drain plug, then the filling plug (upper position) and discharge the oil completely.	5	wrench	1-pc	rag	1/4 kg
4	Tighten the drain plug and supply new oil thru the filling plug. If the oil is about to overflow from the hole, the oil level is normal.	5			gear oil	as stated
5	Install the filling plug and tighten securely.	3				
	Total	20				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 4

3.14. Axle Hub oil: change

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	5				
2	Put a suitable sized container under the drain plug of axle carrier to receive the oil.	1			drain pan	1-pc
					rag	1/4 kg
3	Position the drain plug on the vertical axis (position of 6 o'clock).	1				
4	Loosen the drain plug and filling plug to discharge the oil completely.	5	wrench	1-pc	gear oil	as stated
5	Tighten the drain plug again and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil is normal.	5				
6	Install filling plug and tighten securely.	3				
	Total	20				



3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 4

3.15. A. Check/adjust engine valve clearance

B. Check/retight cylinder head bolt






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Open access	1				
2	Remove parts/accessories to give way for the adjustment of engine valve	5	flat screw driver	1-pc		
			cross screw driver	1-pc		
			plier	1-pc		
			combination wrench	1-pc		
3	Remove valve cover	5			rag	1/4 kg
4	Check/untorque cylinder head bolt	15				
5	Adjust valve clearance	30	feeler gauge	1-set		
6	After valve clearance adjustment, repeat the procedure in reverse order	25			sealant	1-tube
					gasket	1-set
7	Start the engine and check for leak and any distorting noise	5				
	Note: Follow procedure of engine valve clearance/adjustment according to manufacturer's guide and standards					
	Total	86				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 4

3.16. Turbocharger: check/clean



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Leave the engine running at low idling speed for at least a minute after start and a few minutes before it is stopped. This is to safeguard the lubrication of the turbocharger.					
1	Remove the oil filler pipe and drain pipe, then remove the intake air pipe connector and blower housing so that the blower impeller can be seen.	10	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	NOTE: excessive carbon or oil sludge adhering to turbocharger blower may lead to performance deterioration and possible damage. Using light oil as a cleaning agent, remove the carbon, sludge, and other dirt from the blower impeller.	5			light oil	as stated
					rag	1/4 kg
3	Pour in light oil thru the turbocharger oil filler and rotate the blower impeller several times to wash out the sludge.	5				
4	Rotate the impeller by hand at least one turn at speed to check that there is contact noise or catching inside. If the impeller does not turn smoothly, contact the equipment manufacturer for repair or replacement.	10				
5	If there is no abnormality, dry off the light oil with compressed air after inspection, then add engine oil.	5			compressed air	as stated
6	Reassemble in reverse order.	20				
7	Run the engine and if any jarring noises be heard and shows unusual vibration, it must be reconditioned or changed immediately.	5				
						
	Total	60				

3.0. Service Vehicle

DPWH Property Code: H1

Maintenance Activity: PM 4

3.17. Air conditioner refrigerant: check

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Note: Inhaling air conditioner refrigerant gas thru a lit cigarette or other smoking method or inhaling fumes released from a flame contacting refrigerant gas can cause bodily harm or death					
1	Run engine at about 1,800 rpm. Operate for a minimum of ten (10) minutes to stabilize the air conditioning system	10				
2	Press the "HI" fan speed switch to set maximum airflow	1				
	Put the temperature control switch in maximum cooling position					
	Press the "Internal Air Circulation switch					
3	Compare the flow of bubbles in the sight glass of receiver dryer in the following table:	1				
4	Amount of refrigerant: Almost clear. Any bubbles disappear. Normal; No bubbles are seen. High. Withdraw the system with the correct amount of HFC 134a A flow of bubbles is visible. Low. Charge the system with the correct amount of HFC 134a	8			rag	1/4 kg
	Important: Overfilling refrigerant can cause dangerous high-pressure and poor cooling action; and low refrigerant level can cause compressor damage					
	Total	20				




4.0. DUMP TRUCK (H3)

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 2

4.1. Engine oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Park the unit on a firm level ground					
1	Open access	1				
2	Put a suitable container under the drain plug at the bottom of the oil pan	2	drain pan	1-pc		
3	Remove the oil filler cap and oil filter	5	oil filter wrench	1-pc		
4	Remove the drain plug to drain the oil into a container Note: While draining, clean the air filter	20	wrench	1-pc		
5	When engine oil drops intermittently, apply compressed air into the filler hole to hasten draining	9			rag	1-pc
6	Install drain plug and oil filter	8			oil filter	1-pc
7	Fill new engine oil into the filler hole with the specified viscosity/SAE No	10			engine oil	as stated
8	Run the engine and check for leaks	5				
	Total	60				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 2

4.2. Engine oil filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Replace the oil filter every time the oil is changed Remove the oil filter	3	filter wrench	1-pc		
2	Clean the filter housing base and apply a light coat of engine oil to the gasket of the new filter	2			new oil filter	1-pc
					engine oil	as stated
					rag	1/4 kg
3	Fill the new filter with the specified engine oil	1				
4	Screw on the new filter by hand until the gasket just touches the sealing surface. Tighten the filter a further 1/2 turn	3				
5	Start the engine and check that the gasket is sealed. If not, remove the filter and check the sealing surface	3				
	Note: It is important that the new filter is filled with the prescribed engine oil before it is installed. This is to ensure lubrication of the engine immediately after starting					
	Total	12				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 2

4.3. Primary Air filter: clean and replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Do not, under any circumstances, run the engine without air filter or with a damaged one. The degree of engine wear depends largely on the cleanliness of the induction air.					
1	Open the access door at the rear of the cabin	1				
2	Remove the evacuator valve and air cleaner cover	2				
3	Press with both thumbs on primary filter at the same time as you pull it out. This is to prevent the secondary filter from coming out together with the primary filter.	2				
4	Carefully tap the end of the air filter against a soft and clean surface	5				
5	Use clean and dry compressed air, blow the filter from the inside along the folds	5			compressed air	as stated
6	If there is the smallest hole, scratch, crack or other damage, the filter must be discarded	1			rag	1/4 kg
7	Install the primary air filter and the cover	4				
	Total	20				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 2

4.4. Hydraulic drain filter: replace






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	5	wrench	1-pc	 rag	1/4 kg
			screw driver	1-pc		
			plier	1-pc		
4	Place a container under the drain filter and turn the filter counter clockwise to remove it.	5			drain pan	1-pc
5	Fill the new filter with oil, thinly coat O-ring with oil.	1			new filter	1-pc
					hydraulic oil	as stated
6	Install the new filter	7				
	Total	20				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 2

4.5. Engine fan belt: check/replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	<p>Note: A loose fan belt can cause engine overheating, poor charging, and premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing or belt.</p> <p>With the engine shut off, and the starter switch is in the "OFF" position and the controls are tagged, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex approximately 10 mm (0.4 in.)</p>	5	 			
2	To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.	10	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	<p>Replace the belts if it is badly worn, greasy and severely cracked.</p> <p>Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable and if it is frayed or has pieces of material missing.</p>	5				
4	Install the new belts, make sure all pulley must be aligned. The grooves, bearings, shafts are in working order. Brackets are securely clamped. If damaged, replace.	15	 		fan belt	1-pc
5	Repeat activity nos. 1 and 2	15				
	Reminder: Check/adjust the tension of new belts at 50 hours intervals until tension is stabilized and thereafter, every 250 hours.					
	Total	50				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 2

4.6. Axle carrier oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	2				
2	Remove the filling and level checking plug (upper position). If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 2

4.7. Axle Hub oil level: check






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	2				
2	Position the filling and level checking plug on a horizontal axis (position of 3 o'clock) and remove the plug. If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 3

4.8. Fuel filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Exchange filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke. Locate fuel filter inside engine compartment. Position a small container under the filter.	2			container	1/2 pail
					rag	1/4 kg
2	Unscrew fuel filter from head assembly. Discard fuel filter properly.	3	wrench	1-pc		
			screw driver	1-pc		
3	After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench. Note: Coat fuel filter gasket with fuel and fill fuel filter with clean fuel. This will help reduce fuel system priming.	5	filter wrench	1-pc	new fuel filter	1-pc
					fuel oil	as stated
4	If the fuel filter has been replaced, air may need to be bleed using the following <u>FUEL SYSTEM PRIMING</u> : Loosen plug on top of the fuel filter head.	3				
5	Unscrew and pump the hand operated priming pump by the fuel injection pump. Pump priming pump until fuel is present at plug hole in fuel filter head.	5	 			
6	Tighten plug in fuel filter head.	1				
7	Continue to pump the priming pump until a strong resistance is felt. Screw the priming pump knob back into housing to lock the plunger.	3				
8	Start engine and look for signs of leaks. Repeat procedure if necessary.	3				
	Total	25				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 3

4.9. Controls: check/adjust/lubricate






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Controls for: bucket; tilting; tandem;					
1	Lubricate all joints and linkages	20	oiler	1-pc	multi-purpose grease	500 gm
			grease gun	1-set	lubricating oil	as stated
			wrench	1-pc	rag	1/4 kg
2	Check and adjust clearance	5				
3	Clean off surplus grease and oil completely.	5				
	Total	30				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 3

4.10.Air-conditioning system: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: When a leak occurs, dirt will accumulate in the area where the leak is.					
1	All service and inspection of air-conditioning system should be performed with the starter switch in the "O" (Off) position.	1				
2	Check the hoses for damage and cracks.	1				
3	Inspect the condenser for dust and debris. Clean if necessary.	2			detergent	as stated
					water	
					rag	1/4 kg
4	Push the "A/C" switch on in order to energize the magnetic clutch. Check the magnetic clutch for dirt and interference.	2				
5	At correct belt tension, it should be possible to depress the belt approximately 10 mm (0.4 in.). Adjust if necessary.	2	wrench 	1-pc		
			screw driver	1-pc		
6	If the unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into the operator's cabin, clean the air-conditioning outer and inner filters.	5				
7	Open the door in the left front of the machine, then remove the cover by loosening the four wing bolts.	5				
8	Remove the outer filter, then the inner filter and inspect for any damage. If the filter is damaged replace with a new one.	2				
9	Use compressed air to clean the filters. If the filter is very dirty, use a mild soap or detergent and water to clean it.	5			compressed air	as stated
10	If water was used, be certain the filters are completely dry. Install the filters and assemble it in reverse order.	5				
	Total	30				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 3

4.11. Alternator assembly: check/inspect





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	2	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the alternator assembly	30				
4	Overhaul and clean	40			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease, bushing for wear. Replace if necessary.	5				
6	Assemble the alternator and install. If possible, check the alternator ratings on bench testing machine.	30	bench testing machine	1-set		
7	Check the alternator belt tension by pressing downwards on the belt, midway between the fan pulley and alternator pulley.	5				
8	Adjust the belt tension by loosening the alternator adjustment plate bolts. The belt should flex approximately 10 mm (0.4 in.) Retighten the bolts.	5				
9	Run the engine and check for any jarring noise and excessive vibration.	2				
	Total	120				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 3

4.12. Starting motor: check/inspect



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	1	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the starting motor	30				
4	Overhaul and clean	25			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease; bushing for wear. Replace if necessary.	1				
6	Assemble the starting motor and install. If possible, check the starting motor ratings on bench testing machine.	30	bench testing machine	1-set		
9	Run the engine and check for any jarring noise and vibration.	2				
	Total	90				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 3

4.13. Water separator element: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Turn priming pump counterclockwise to unlock the plunger then turn shut-off valve clockwise 90 degrees	1	wrench	1-pc		
			 screw driver	1-pc		
			plier	1-pc		
2	Place a suitable sized container under the drain hose	1			drain pan	1-pc
					rag	1/4 kg
3	Open drain valve and drain the fuel from the water separator, afterwards close the drain valve	5				
4	Disconnect sensor connector	1				
5	Remove bowl assembly and set it aside for installation and remove filter element	5	filter wrench	1-pc		
6	Clean the inside surface of the filter head and of the bowl; check the condition of the O-ring. Replace the O-ring if damaged	30				
7	Apply a small amount of fuel to the gasket of the new filter; install the new filter by hand until it contacts the mounting surface. Tighten the filter	30			new filter	1-pc
					fuel oil	as stated
8	Install bowl assembly; reconnect sensor connector	5				
9	Turn shut-off valve counterclockwise 90 degrees	2				
10	Bleed the system	10				
	Total	90				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.14. Hydraulic oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Warning! Take care when changing the oil. Hot oil can cause burns on unprotected skin					
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	3	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc	rag	1/4 kg
4	Open the cover after removing the screws and remove O-ring then pull out the strainer.	20				
6	Place a suitable container under the drain plug of hydraulic tank	1			drain pan	1-pc
7	Remove the drain plug	3				
8	Drain the oil into the container. Wait till the last drop of oil for few minutes	20				
9	Reinstall the drain plug	5				
10	Clean the magnetic rings of strainer thoroughly. Check O-ring and if damaged, replace it with a new one and reinstall the strainer.	5			compressed air	as stated
11	Refill oil and reinstall the cover	20			hydraulic oil	as stated
12	Check the oil in the sight gauge.	1				
13	Perform test run to check for any leaks	10				
	Total	90				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.15. Hydraulic pilot filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	2				
4	Place a container under the pilot filter.	1			drain pan	1-pc
5	Unscrew/remove the filter bowl or canister, O-ring and inner element. Note: The bowl/canister will be filled with oil. Use caution when removing this assembly.	5	wrench	1-pc	rag	1/4 kg
			 plier	1-pc		
6	Install a new inner filter element and O-ring. Apply a small amount of oil around the entire O-ring.	5			pilot filter element	1-pc
					o-ring	1-pc
					hydraulic oil	as stated
7	Reinstall the filter bowl/canister.	2				
8	After changing the pilot filter element, vent air from pump and check level of hydraulic oil tank.	3				
	Total	20				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.16.Transfer gearbox oil: change




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case could eject the oil and plug. Put a suitable sized container , above 3 liters, under the drain plug of transfer gearbox to receive the oil.	15			drain pan	1-pc
4	Loosen the drain plug slowly, discharge the oil completely.	15	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	Tighten the drain plug again and remove the filling plug and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil level is normal. Then install the filling plug.	3			engine oil	as stated
6	Check the oil level once again after a driving time of about 5 minutes. If necessary, refill the oil.	5				
	Total	40				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.17. Transfer gearbox: air bleeding



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	<u>Note:</u> After initial assembly of the machine or disconnecting high/low speed pressure line (from pump to transfer gearbox) and remounting, bleed the air from the transfer gearbox before travelling the machine. Releaser the parking brake.	15				
4	Set the gear speed change lever to 2nd. Open bleeder of the brake and bleed it for approximately 20 seconds.	3	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	When the brake is bled the first time, additionally open also bleeder of the emergency actuating device to bring it into its initial position. In this case no oil flows out.	3				
6	Close both bleeders.	1				
7	Set the gear speed change lever to 1st (low speed). Open bleeder of the clutch and bleed it for approximately 20 seconds.	2				
8	Close bleeder of the clutch.	1				
9	Repeat bleeding the brake and clutch 2 times each for approximately 20 seconds. At the last bleeding procedure no air bubbles are allowed to be visible in the oil anymore.	10				
10	Check all screws connections for leaks. <u>Important:</u> If the air in the transfer gearbox is not vented out, a serious fault may develop, such as damage of the clutch in the transfer gearbox may occur.	3				
Total		40				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.18. Axle Carrier oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	5				
2	Put a suitable container under the drain plug (lower position) of axle carrier to receive the oil.	2			drain pan	1-pc
3	Loosen the drain plug, then the filling plug (upper position) and discharge the oil completely.	5	wrench	1-pc	rag	1/4 kg
4	Tighten the drain plug and supply new oil thru the filling plug. If the oil is about to overflow from the hole, the oil level is normal.	5			gear oil	as stated
5	Install the filling plug and tighten securely.	3				
	Total	20				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.19. Axle Hub oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	5				
2	Put a suitable sized container under the drain plug of axle carrier to receive the oil.	1			drain pan	1-pc
					rag	1/4 kg
3	Position the drain plug on the vertical axis (position of 6 o'clock).	1				
4	Loosen the drain plug and filling plug to discharge the oil completely.	5	wrench	1-pc	gear oil	as stated
5	Tighten the drain plug again and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil is normal.	5				
6	Install filling plug and tighten securely.	3				
	Total	20				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.20. Hydraulic System: venting and priming

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: If pump is run without sufficient oil in the main hydraulic pump, damage can occur. Always vent pump of air after draining hydraulic system. With the engine stopped, remove vent plug to see if any oil is present.	3	wrench 	1-pc	rag	1/4 kg
2	If oil is not present, fill pump with oil thru port.	5			hydraulic oil	as stated
3	Install vent plug first.	2				
4	Start engine and run it for several minutes at low idle engine speed. This will pressurize the hydraulic oil tank and system.	5	 			
5	Slowly loosen vent plug several turns, until hydraulic oil flows out of plug. This shows that air has been released. Tighten the plug.	5				
	Total	20				




4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.21. A. Check/adjust engine valve clearance

B. Check/retight cylinder head bolt






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Open access	1				
2	Remove parts/accessories to give way for the adjustment of engine valve	5	flat screw driver	1-pc		
			cross screw driver	1-pc		
			plier	1-pc		
			combination wrench	1-pc		
3	Remove valve cover	5			rag	1/4 kg
4	Check/untorque cylinder head bolt	15				
5	Adjust valve clearance	30	feeler gauge	1-set		
6	After valve clearance adjustment, repeat the procedure in reverse order	25			sealant	1-tube
					gasket	1-set
7	Start the engine and check for leak and any distorting noise	5				
	Note: Follow procedure of engine valve clearance/adjustment according to manufacturer's guide and standards					
	Total	86				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.22. Turbocharger: check/clean



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Leave the engine running at low idling speed for at least a minute after start and a few minutes before it is stopped. This is to safeguard the lubrication of the turbocharger.					
1	Remove the oil filler pipe and drain pipe, then remove the intake air pipe connector and blower housing so that the blower impeller can be seen.	10	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	NOTE: excessive carbon or oil sludge adhering to turbocharger blower may lead to performance deterioration and possible damage. Using light oil as a cleaning agent, remove the carbon, sludge, and other dirt from the blower impeller.	5			light oil	as stated
					rag	1/4 kg
3	Pour in light oil thru the turbocharger oil filler and rotate the blower impeller several times to wash out the sludge.	5				
4	Rotate the impeller by hand at least one turn at speed to check that there is contact noise or catching inside. If the impeller does not turn smoothly, contact the equipment manufacturer for repair or replacement.	10				
5	If there is no abnormality, dry off the light oil with compressed air after inspection, then add engine oil.	5			compressed air	as stated
6	Reassemble in reverse order.	20				
7	Run the engine and if any jarring noises be heard and shows unusual vibration, it must be reconditioned or changed immediately.	5				
						
	Total	60				

4.0. Dump Truck

DPWH Property Code: H3

Maintenance Activity: PM 4

4.23. Air conditioner refrigerant: check

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Note: Inhaling air conditioner refrigerant gas thru a lit cigarette or other smoking method or inhaling fumes released from a flame contacting refrigerant gas can cause bodily harm or death					
1	Run engine at about 1,800 rpm. Operate for a minimum of ten (10) minutes to stabilize the air conditioning system	10				
2	Press the "HI" fan speed switch to set maximum airflow	1				
	Put the temperature control switch in maximum cooling position					
	Press the "Internal Air Circulation switch					
3	Compare the flow of bubbles in the sight glass of receiver dryer in the following table:	1				
4	Amount of refrigerant: Almost clear. Any bubbles disappear. Normal; No bubbles are seen. High. Withdraw the system with the correct amount of HFC 134a A flow of bubbles is visible. Low. Charge the system with the correct amount of HFC 134a	8			rag	1/4 kg
	Important: Overfilling refrigerant can cause dangerous high-pressure and poor cooling action; and low refrigerant level can cause compressor damage					
	Total	20				




5.0. SHUTTLE BUS (H12)

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 2

5.1. Engine oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Park the unit on a firm level ground					
1	Open access	1				
2	Put a suitable container under the drain plug at the bottom of the oil pan	2	drain pan	1-pc		
3	Remove the oil filler cap and oil filter	5	oil filter wrench	1-pc		
4	Remove the drain plug to drain the oil into a container Note: While draining, clean the air filter	20	wrench	1-pc		
5	When engine oil drops intermittently, apply compressed air into the filler hole to hasten draining	9			rag	1-pc
6	Install drain plug and oil filter	8			oil filter	1-pc
7	Fill new engine oil into the filler hole with the specified viscosity/SAE No	10			engine oil	as stated
8	Run the engine and check for leaks	5				
	Total	60				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 2

5.2. Engine oil filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Replace the oil filter every time the oil is changed Remove the oil filter	3	filter wrench	1-pc		
2	Clean the filter housing base and apply a light coat of engine oil to the gasket of the new filter	2			new oil filter	1-pc
					engine oil	as stated
					rag	1/4 kg
3	Fill the new filter with the specified engine oil	1				
4	Screw on the new filter by hand until the gasket just touches the sealing surface. Tighten the filter a further 1/2 turn	3				
5	Start the engine and check that the gasket is sealed. If not, remove the filter and check the sealing surface	3				
	Note: It is important that the new filter is filled with the prescribed engine oil before it is installed. This is to ensure lubrication of the engine immediately after starting					
	Total	12				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 2

5.3. Primary Air filter: clean and replace






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Do not, under any circumstances, run the engine without air filter or with a damaged one. The degree of engine wear depends largely on the cleanliness of the induction air.					
1	Open the access door at the rear of the cabin	1				
2	Remove the evacuator valve and air cleaner cover	2				
3	Press with both thumbs on primary filter at the same time as you pull it out. This is to prevent the secondary filter from coming out together with the primary filter.	2				
4	Carefully tap the end of the air filter against a soft and clean surface	5				
5	Use clean and dry compressed air, blow the filter from the inside along the folds	5			compressed air	as stated
6	If there is the smallest hole, scratch, crack or other damage, the filter must be discarded	1			rag	1/4 kg
7	Install the primary air filter and the cover	4				
	Total	20				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 2

5.4. Engine fan belt: check/replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	<p>Note: A loose fan belt can cause engine overheating, poor charging, and premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing or belt.</p> <p>With the engine shut off, and the starter switch is in the "OFF" position and the controls are tagged, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex approximately 10 mm (0.4 in.)</p>	5	 			
2	To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.	10	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	<p>Replace the belts if it is badly worn, greasy and severely cracked.</p> <p>Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable and if it is frayed or has pieces of material missing.</p>	5				
4	Install the new belts, make sure all pulley must be aligned. The grooves, bearings, shafts are in working order. Brackets are securely clamped. If damaged, replace.	15	 		fan belt	1-pc
5	Repeat activity nos. 1 and 2	15				
	Reminder: Check/adjust the tension of new belts at 50 hours intervals until tension is stabilized and thereafter, every 250 hours.					
	Total	50				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 2

5.5. Axle carrier oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	2				
2	Remove the filling and level checking plug (upper position). If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 2

5.6. Axle Hub oil level: check






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	2				
2	Position the filling and level checking plug on a horizontal axis (position of 3 o'clock) and remove the plug. If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 3

5.7. Fuel filter: replace






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Exchange filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke.	2			container	1/2 pail
	Locate fuel filter inside engine compartment. Position a small container under the filter.				rag	1/4 kg
2	Unscrew fuel filter from head assembly. Discard fuel filter properly.	3	wrench	1-pc		
			screw driver	1-pc		
3	After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench. Note: Coat fuel filter gasket with fuel and fill fuel filter with clean fuel. This will help reduce fuel system priming.	5	filter wrench	1-pc	new fuel filter	1-pc
					fuel oil	as stated
4	If the fuel filter has been replaced, air may need to be bled using the following <u>FUEL SYSTEM PRIMING</u> : Loosen plug on top of the fuel filter head.	3				
5	Unscrew and pump the hand operated priming pump by the fuel injection pump. Pump priming pump until fuel is present at plug hole in fuel filter head.	5	 			
6	Tighten plug in fuel filter head.	1				
7	Continue to pump the priming pump until a strong resistance is felt. Screw the priming pump knob back into housing to lock the plunger.	3				
8	Start engine and look for signs of leaks. Repeat procedure if necessary.	3				
	Total	25				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 3

5.8. Air-conditioning system: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: When a leak occurs, dirt will accumulate in the area where the leak is.					
1	All service and inspection of air-conditioning system should be performed with the starter switch in the "O" (Off) position.	1				
2	Check the hoses for damage and cracks.	1				
3	Inspect the condenser for dust and debris. Clean if necessary.	2			detergent	as
					water	stated
					rag	1/4 kg
4	Push the "A/C" switch on in order to energize the magnetic clutch. Check the magnetic clutch for dirt and interference.	2				
5	At correct belt tension, it should be possible to depress the belt approximately 10 mm (0.4 in.). Adjust if necessary.	2	wrench 	1-pc		
			screw driver	1-pc		
6	If the unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into the operator's cabin, clean the air-conditioning outer and inner filters.	5				
7	Open the door in the left front of the machine, then remove the cover by loosening the four wing bolts.	5				
8	Remove the outer filter, then the inner filter and inspect for any damage. If the filter is damaged replace with a new one.	2				
9	Use compressed air to clean the filters. If the filter is very dirty, use a mild soap or detergent and water to clean it.	5			compressed air	as stated
10	If water was used, be certain the filters are completely dry. Install the filters and assemble it in reverse order.	5				
	Total	30				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 3

5.9. Alternator assembly: check/inspect





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	2	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the alternator assembly	30				
4	Overhaul and clean	40			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease, bushing for wear. Replace if necessary.	5				
6	Assemble the alternator and install. If possible, check the alternator ratings on bench testing machine.	30	bench testing machine	1-set		
7	Check the alternator belt tension by pressing downwards on the belt, midway between the fan pulley and alternator pulley.	5				
8	Adjust the belt tension by loosening the alternator adjustment plate bolts. The belt should flex approximately 10 mm (0.4 in.) Retighten the bolts.	5				
9	Run the engine and check for any jarring noise and excessive vibration.	2				
	Total	120				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 3

5.10. Starting motor: check/inspect



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	1	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the starting motor	30				
4	Overhaul and clean	25			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease; bushing for wear. Replace if necessary.	1				
6	Assemble the starting motor and install. If possible, check the starting motor ratings on bench testing machine.	30	bench testing machine	1-set		
9	Run the engine and check for any jarring noise and vibration.	2				
	Total	90				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 3

5.11. Water separator element: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Turn priming pump counterclockwise to unlock the plunger then turn shut-off valve clockwise 90 degrees	1	wrench	1-pc		
			 screw driver	1-pc		
			plier	1-pc		
2	Place a suitable sized container under the drain hose	1			drain pan	1-pc
					rag	1/4 kg
3	Open drain valve and drain the fuel from the water separator, afterwards close the drain valve	5				
4	Disconnect sensor connector	1				
5	Remove bowl assembly and set it aside for installation and remove filter element	5	filter wrench	1-pc		
6	Clean the inside surface of the filter head and of the bowl; check the condition of the O-ring. Replace the O-ring if damaged	30				
7	Apply a small amount of fuel to the gasket of the new filter; install the new filter by hand until it contacts the mounting surface. Tighten the filter	30			new filter	1-pc
					fuel oil	as stated
8	Install bowl assembly; reconnect sensor connector	5				
9	Turn shut-off valve counterclockwise 90 degrees	2				
10	Bleed the system	10				
	Total	90				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 4

5.12. Transfer gearbox oil: change




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case could eject the oil and plug. Put a suitable sized container , above 3 liters, under the drain plug of transfer gearbox to receive the oil.	15			drain pan	1-pc
4	Loosen the drain plug slowly, discharge the oil completely.	15	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	Tighten the drain plug again and remove the filling plug and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil level is normal. Then install the filling plug.	3			engine oil	as stated
6	Check the oil level once again after a driving time of about 5 minutes. If necessary, refill the oil.	5				
	Total	40				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 4

5.13. Transfer gearbox: air bleeding



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	<u>Note:</u> After initial assembly of the machine or disconnecting high/low speed pressure line (from pump to transfer gearbox) and remounting, bleed the air from the transfer gearbox before travelling the machine. Releaser the parking brake.	15				
4	Set the gear speed change lever to 2nd. Open bleeder of the brake and bleed it for approximately 20 seconds.	3	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	When the brake is bled the first time, additionally open also bleeder of the emergency actuating device to bring it into its initial position. In this case no oil flows out.	3				
6	Close both bleeders.	1				
7	Set the gear speed change lever to 1st (low speed). Open bleeder of the clutch and bleed it for approximately 20 seconds.	2				
8	Close bleeder of the clutch.	1				
9	Repeat bleeding the brake and clutch 2 times each for approximately 20 seconds. At the last bleeding procedure no air bubbles are allowed to be visible in the oil anymore.	10				
10	Check all screws connections for leaks. <u>Important:</u> If the air in the transfer gearbox is not vented out, a serious fault may develop, such as damage of the clutch in the transfer gearbox may occur.	3				
	Total	40				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 4

5.14. Axle Carrier oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	5				
2	Put a suitable container under the drain plug (lower position) of axle carrier to receive the oil.	2			drain pan	1-pc
3	Loosen the drain plug, then the filling plug (upper position) and discharge the oil completely.	5	wrench	1-pc	rag	1/4 kg
4	Tighten the drain plug and supply new oil thru the filling plug. If the oil is about to overflow from the hole, the oil level is normal.	5			gear oil	as stated
5	Install the filling plug and tighten securely.	3				
	Total	20				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 4

5.15. Axle Hub oil: change

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	5				
2	Put a suitable sized container under the drain plug of axle carrier to receive the oil.	1			drain pan	1-pc
					rag	1/4 kg
3	Position the drain plug on the vertical axis (position of 6 o'clock).	1				
4	Loosen the drain plug and filling plug to discharge the oil completely.	5	wrench	1-pc	gear oil	as stated
5	Tighten the drain plug again and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil is normal.	5				
6	Install filling plug and tighten securely.	3				
	Total	20				



5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 4

5.16. A. Check/adjust engine valve clearance

B. Check/retight cylinder head bolt






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Open access	1				
2	Remove parts/accessories to give way for the adjustment of engine valve	5	flat screw driver	1-pc		
			cross screw driver	1-pc		
			plier	1-pc		
			combination wrench	1-pc		
3	Remove valve cover	5			rag	1/4 kg
4	Check/untorque cylinder head bolt	15				
5	Adjust valve clearance	30	feeler gauge	1-set		
6	After valve clearance adjustment, repeat the procedure in reverse order	25			sealant	1-tube
					gasket	1-set
7	Start the engine and check for leak and any distorting noise	5				
	Note: Follow procedure of engine valve clearance/adjustment according to manufacturer's guide and standards					
	Total	86				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 4

5.17. Turbocharger: check/clean



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Leave the engine running at low idling speed for at least a minute after start and a few minutes before it is stopped. This is to safeguard the lubrication of the turbocharger.					
1	Remove the oil filler pipe and drain pipe, then remove the intake air pipe connector and blower housing so that the blower impeller can be seen.	10	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	NOTE: excessive carbon or oil sludge adhering to turbocharger blower may lead to performance deterioration and possible damage. Using light oil as a cleaning agent, remove the carbon, sludge, and other dirt from the blower impeller.	5			light oil	as stated
					rag	1/4 kg
3	Pour in light oil thru the turbocharger oil filler and rotate the blower impeller several times to wash out the sludge.	5				
4	Rotate the impeller by hand at least one turn at speed to check that there is contact noise or catching inside. If the impeller does not turn smoothly, contact the equipment manufacturer for repair or replacement.	10				
5	If there is no abnormality, dry off the light oil with compressed air after inspection, then add engine oil.	5			compressed air	as stated
6	Reassemble in reverse order.	20				
7	Run the engine and if any jarring noises be heard and shows unusual vibration, it must be reconditioned or changed immediately.	5				
						
	Total	60				

5.0. Shuttle Bus

DPWH Property Code: H12

Maintenance Activity: PM 4

5.18. Air conditioner refrigerant: check

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Note: Inhaling air conditioner refrigerant gas thru a lit cigarette or other smoking method or inhaling fumes released from a flame contacting refrigerant gas can cause bodily harm or death					
1	Run engine at about 1,800 rpm. Operate for a minimum of ten (10) minutes to stabilize the air conditioning system	10				
2	Press the "HI" fan speed switch to set maximum airflow	1				
	Put the temperature control switch in maximum cooling position					
	Press the "Internal Air Circulation switch					
3	Compare the flow of bubbles in the sight glass of receiver dryer in the following table:	1				
4	Amount of refrigerant: Almost clear. Any bubbles disappear. Normal; No bubbles are seen. High. Withdraw the system with the correct amount of HFC 134a A flow of bubbles is visible. Low. Charge the system with the correct amount of HFC 134a	8			rag	1/4 kg
	Important: Overfilling refrigerant can cause dangerous high-pressure and poor cooling action; and low refrigerant level can cause compressor damage					
	Total	20				




6.0. CRAWLER TRACTOR (L1)

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 2

6.1. Engine oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Park the unit on a firm level ground					
1	Open access	1				
2	Put a suitable container under the drain plug at the bottom of the oil pan	2	drain pan	1-pc		
3	Remove the oil filler cap and oil filter	5	oil filter wrench	1-pc		
4	Remove the drain plug to drain the oil into a container Note: While draining, clean the air filter	20	wrench	1-pc		
5	When engine oil drops intermittently, apply compressed air into the filler hole to hasten draining	9			rag	1-pc
6	Install drain plug and oil filter	8			oil filter	1-pc
7	Fill new engine oil into the filler hole with the specified viscosity/SAE No	10			engine oil	as stated
8	Run the engine and check for leaks	5				
	Total	60				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 2

6.2. Engine oil filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Replace the oil filter every time the oil is changed Remove the oil filter	3	filter wrench	1-pc		
2	Clean the filter housing base and apply a light coat of engine oil to the gasket of the new filter	2			new oil filter	1-pc
					engine oil	as stated
					rag	1/4 kg
3	Fill the new filter with the specified engine oil	1				
4	Screw on the new filter by hand until the gasket just touches the sealing surface. Tighten the filter a further 1/2 turn	3				
5	Start the engine and check that the gasket is sealed. If not, remove the filter and check the sealing surface	3				
	Note: It is important that the new filter is filled with the prescribed engine oil before it is installed. This is to ensure lubrication of the engine immediately after starting					
	Total	12				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 2

6.3. Primary Air filter: clean and replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Do not, under any circumstances, run the engine without air filter or with a damaged one. The degree of engine wear depends largely on the cleanliness of the induction air.					
1	Open the access door at the rear of the cabin	1				
2	Remove the evacuator valve and air cleaner cover	2				
3	Press with both thumbs on primary filter at the same time as you pull it out. This is to prevent the secondary filter from coming out together with the primary filter.	2				
4	Carefully tap the end of the air filter against a soft and clean surface	5				
5	Use clean and dry compressed air, blow the filter from the inside along the folds	5			compressed air	as stated
6	If there is the smallest hole, scratch, crack or other damage, the filter must be discarded	1			rag	1/4 kg
7	Install the primary air filter and the cover	4				
	Total	20				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 2

6.4. Hydraulic drain filter: replace






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	5	wrench	1-pc	 rag	1/4 kg
			screw driver	1-pc		
			plier	1-pc		
4	Place a container under the drain filter and turn the filter counter clockwise to remove it.	5			drain pan	1-pc
5	Fill the new filter with oil, thinly coat O-ring with oil.	1			new filter	1-pc
					hydraulic oil	as stated
6	Install the new filter	7				
	Total	20				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 2

6.5. Engine fan belt: check/replace




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	<p>Note: A loose fan belt can cause engine overheating, poor charging, and premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing or belt.</p> <p>With the engine shut off, and the starter switch is in the "OFF" position and the controls are tagged, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex approximately 10 mm (0.4 in.)</p>	5	 			
2	To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.	10	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	<p>Replace the belts if it is badly worn, greasy and severely cracked.</p> <p>Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable and if it is frayed or has pieces of material missing.</p>	5				
4	Install the new belts, make sure all pulley must be aligned. The grooves, bearings, shafts are in working order. Brackets are securely clamped. If damaged, replace.	15	 		fan belt	1-pc
5	Repeat activity nos. 1 and 2	15				
	Reminder: Check/adjust the tension of new belts at 50 hours intervals until tension is stabilized and thereafter, every 250 hours.					
	Total	50				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 2

6.6. Front attachments, cylinders, pins and ball joints: greasing






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Wipe off the grease nipples and the grease gun before greasing, to avoid introducing sand and dirt particles with the grease.					
1	Position the machine on a firm, level ground. Rest the blade on the ground and shut down the engine.	5				
2	Press the grease fitting and inject grease with the use of grease gun on the marked points:	25	grease gun	1-set	multi-purpose grease	500 gm
	Leaning cylinder pin		wrench	1-pc		1/4 kg
	Tie rod		screw driver	1-pc		
	Knuckle bracket king pin					
	Leaning pin					
	Steering cylinder					
	Front axle center pin					
	Drawbar ball joint					
	Scarifier ball joint					
	Scarifier cylinder pin					
	Blade lift cylinder yoke					
	Blade lift cylinder ball joint					
	Drawbar side shift cylinder ball					
	Bank control guide					
	Articulation center pin					
	Articulation cylinder pin					
3	After injection, clean off the old grease that has been purged.	10				
	Total	40				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 3

6.7. Fuel filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Exchange filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke.	2			container	1/2 pail
	Locate fuel filter inside engine compartment. Position a small container under the filter.				rag	1/4 kg
2	Unscrew fuel filter from head assembly. Discard fuel filter properly.	3	wrench	1-pc		
			screw driver	1-pc		
3	After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench. Note: Coat fuel filter gasket with fuel and fill fuel filter with clean fuel. This will help reduce fuel system priming.	5	filter wrench	1-pc	new fuel filter	1-pc
					fuel oil	as stated
4	If the fuel filter has been replaced, air may need to be bled using the following <u>FUEL SYSTEM PRIMING</u> : Loosen plug on top of the fuel filter head.	3				
5	Unscrew and pump the hand operated priming pump by the fuel injection pump. Pump priming pump until fuel is present at plug hole in fuel filter head.	5	 			
6	Tighten plug in fuel filter head.	1				
7	Continue to pump the priming pump until a strong resistance is felt. Screw the priming pump knob back into housing to lock the plunger.	3				
8	Start engine and look for signs of leaks. Repeat procedure if necessary.	3				
	Total	25				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 3

6.8. Controls: check/adjust/lubricate






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Controls for: blade; tilting; tandem;					
1	Lubricate all joints and linkages	20	oiler	1-pc	multi-purpose grease	500 gm
			grease gun	1-set	lubricating oil	as stated
			wrench	1-pc	rag	1/4 kg
2	Check and adjust clearance	5				
3	Clean off surplus grease and oil completely.	5				
	Total	30				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 3

6.9. Air-conditioning system: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: When a leak occurs, dirt will accumulate in the area where the leak is.					
1	All service and inspection of air-conditioning system should be performed with the starter switch in the "O" (Off) position.	1				
2	Check the hoses for damage and cracks.	1				
3	Inspect the condenser for dust and debris. Clean if necessary.	2			detergent	as stated
					water	
					rag	1/4 kg
4	Push the "A/C" switch on in order to energize the magnetic clutch. Check the magnetic clutch for dirt and interference.	2				
5	At correct belt tension, it should be possible to depress the belt approximately 10 mm (0.4 in.). Adjust if necessary.	2	wrench 	1-pc		
			screw driver	1-pc		
6	If the unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into the operator's cabin, clean the air-conditioning outer and inner filters.	5				
7	Open the door in the left front of the machine, then remove the cover by loosening the four wing bolts.	5				
8	Remove the outer filter, then the inner filter and inspect for any damage. If the filter is damaged replace with a new one.	2				
9	Use compressed air to clean the filters. If the filter is very dirty, use a mild soap or detergent and water to clean it.	5			compressed air	as stated
10	If water was used, be certain the filters are completely dry. Install the filters and assemble it in reverse order.	5				
	Total	30				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 3

6.10. Alternator assembly: check/inspect





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	2	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the alternator assembly	30				
4	Overhaul and clean	40			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease, bushing for wear. Replace if necessary.	5				
6	Assemble the alternator and install. If possible, check the alternator ratings on bench testing machine.	30	bench testing machine	1-set		
7	Check the alternator belt tension by pressing downwards on the belt, midway between the fan pulley and alternator pulley.	5				
8	Adjust the belt tension by loosening the alternator adjustment plate bolts. The belt should flex approximately 10 mm (0.4 in.) Retighten the bolts.	5				
9	Run the engine and check for any jarring noise and excessive vibration.	2				
	Total	120				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 3

6.11. Starting motor: check/inspect




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	1	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the starting motor	30				
4	Overhaul and clean	25			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease; bushing for wear. Replace if necessary.	1				
6	Assemble the starting motor and install. If possible, check the starting motor ratings on bench testing machine.	30	bench testing machine	1-set		
9	Run the engine and check for any jarring noise and vibration.	2				
	Total	90				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 3

6.12. Water separator element: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Turn priming pump counterclockwise to unlock the plunger then turn shut-off valve clockwise 90 degrees	1	 wrench	1-pc		
			 screw driver	1-pc		
			plier	1-pc		
2	Place a suitable sized container under the drain hose	1			drain pan	1-pc
					rag	1/4 kg
3	Open drain valve and drain the fuel from the water separator, afterwards close the drain valve	5				
4	Disconnect sensor connector	1				
5	Remove bowl assembly and set it aside for installation and remove filter element	5	filter wrench	1-pc		
6	Clean the inside surface of the filter head and of the bowl; check the condition of the O-ring. Replace the O-ring if damaged	30				
7	Apply a small amount of fuel to the gasket of the new filter; install the new filter by hand until it contacts the mounting surface. Tighten the filter	30			new filter	1-pc
					fuel oil	as stated
8	Install bowl assembly; reconnect sensor connector	5				
9	Turn shut-off valve counterclockwise 90 degrees	2				
10	Bleed the system	10				
	Total	90				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.13. Hydraulic oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Warning! Take care when changing the oil. Hot oil can cause burns on unprotected skin					
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	3	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc	rag	1/4 kg
4	Open the cover after removing the screws and remove O-ring then pull out the strainer.	20				
6	Place a suitable container under the drain plug of hydraulic tank	1			drain pan	1-pc
7	Remove the drain plug	3				
8	Drain the oil into the container. Wait till the last drop of oil for few minutes	20				
9	Reinstall the drain plug	5				
10	Clean the magnetic rings of strainer thoroughly. Check O-ring and if damaged, replace it with a new one and reinstall the strainer.	5			compressed air	as stated
11	Refill oil and reinstall the cover	20			hydraulic oil	as stated
12	Check the oil in the sight gauge.	1				
13	Perform test run to check for any leaks	10				
	Total	90				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.14. Hydraulic pilot filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	2				
4	Place a container under the pilot filter.	1			drain pan	1-pc
5	Unscrew/remove the filter bowl or canister, O-ring and inner element. Note: The bowl/canister will be filled with oil. Use caution when removing this assembly.	5	wrench	1-pc	rag	1/4 kg
			 plier	1-pc		
6	Install a new inner filter element and O-ring. Apply a small amount of oil around the entire O-ring.	5			pilot filter element	1-pc
					o-ring	1-pc
					hydraulic oil	as stated
7	Reinstall the filter bowl/canister.	2				
8	After changing the pilot filter element, vent air from pump and check level of hydraulic oil tank.	3				
	Total	20				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.15. Transfer gearbox oil: change




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case could eject the oil and plug. Put a suitable sized container , above 3 liters, under the drain plug of transfer gearbox to receive the oil.	15			drain pan	1-pc
4	Loosen the drain plug slowly, discharge the oil completely.	15	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	Tighten the drain plug again and remove the filling plug and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil level is normal. Then install the filling plug.	3			engine oil	as stated
6	Check the oil level once again after a driving time of about 5 minutes. If necessary, refill the oil.	5				
	Total	40				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.16.Transfer gearbox: air bleeding



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	<u>Note:</u> After initial assembly of the machine or disconnecting high/low speed pressure line (from pump to transfer gearbox) and remounting, bleed the air from the transfer gearbox before travelling the machine. Releaser the parking brake.	15				
4	Set the gear speed change lever to 2nd. Open bleeder of the brake and bleed it for approximately 20 seconds.	3	wrench screw driver	1-pc 1-pc	rag	1/4 kg
5	When the brake is bled the first time, additionally open also bleeder of the emergency actuating device to bring it into its initial position. In this case no oil flows out.	3				
6	Close both bleeders.	1				
7	Set the gear speed change lever to 1st (low speed). Open bleeder of the clutch and bleed it for approximately 20 seconds.	2				
8	Close bleeder of the clutch.	1				
9	Repeat bleeding the brake and clutch 2 times each for approximately 20 seconds. At the last bleeding procedure no air bubbles are allowed to be visible in the oil anymore.	10				
10	Check all screws connections for leaks. <u>Important:</u> If the air in the transfer gearbox is not vented out, a serious fault may develop, such as damage of the clutch in the transfer gearbox may occur.	3				
	Total	40				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.17. Travel reduction device oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Note: Drain and replace the oil after the first 250 hours of operation and 1000 hours thereafter. Rotate the track until the three (3) ports are in their proper positions., That is, Port 1 is the level plug, Port 2 is the drain plug and Port 3 is the fill plug.	3				
4	Place a container under the drain plug and remove the plugs (1 to 3), to drain the travel reduction gear oil.	5	wrench	1-pc	drain pan	1-pc
					rag	1/4 kg
5	Install the drain plug. Refill the travel reduction gear case with fluid thru the fill port until the fluid level is at level port. Install the level plug and fill plug.	5			gear oil	as stated
	Total	15				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.18. Hydraulic System: venting and priming

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: If pump is run without sufficient oil in the main hydraulic pump, damage can occur. Always vent pump of air after draining hydraulic system. With the engine stopped, remove vent plug to see if any oil is present.	3	wrench 	1-pc	rag	1/4 kg
2	If oil is not present, fill pump with oil thru port.	5			hydraulic oil	as stated
3	Install vent plug first.	2				
4	Start engine and run it for several minutes at low idle engine speed. This will pressurize the hydraulic oil tank and system.	5	 			
5	Slowly loosen vent plug several turns, until hydraulic oil flows out of plug. This shows that air has been released. Tighten the plug.	5				
	Total	20				



6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.19. A. Check/adjust engine valve clearance

B. Check/retight cylinder head bolt






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Open access	1				
2	Remove parts/accessories to give way for the adjustment of engine valve	5	flat screw driver	1-pc		
			cross screw driver	1-pc		
			plier	1-pc		
			combination wrench	1-pc		
3	Remove valve cover	5			rag	1/4 kg
4	Check/untorque cylinder head bolt	15				
5	Adjust valve clearance	30	feeler gauge	1-set		
6	After valve clearance adjustment, repeat the procedure in reverse order	25			sealant	1-tube
					gasket	1-set
7	Start the engine and check for leak and any distorting noise	5				
	Note: Follow procedure of engine valve clearance/adjustment according to manufacturer's guide and standards					
	Total	86				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.20. Turbocharger: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Leave the engine running at low idling speed for at least a minute after start and a few minutes before it is stopped. This is to safeguard the lubrication of the turbocharger.					
1	Remove the oil filler pipe and drain pipe, then remove the intake air pipe connector and blower housing so that the blower impeller can be seen.	10	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	NOTE: excessive carbon or oil sludge adhering to turbocharger blower may lead to performance deterioration and possible damage. Using light oil as a cleaning agent, remove the carbon, sludge, and other dirt from the blower impeller.	5			light oil	as stated
					rag	1/4 kg
3	Pour in light oil thru the turbocharger oil filler and rotate the blower impeller several times to wash out the sludge.	5				
4	Rotate the impeller by hand at least one turn at speed to check that there is contact noise or catching inside. If the impeller does not turn smoothly, contact the equipment manufacturer for repair or replacement.	10				
5	If there is no abnormality, dry off the light oil with compressed air after inspection, then add engine oil.	5			compressed air	as stated
6	Reassemble in reverse order.	20				
7	Run the engine and if any jarring noises be heard and shows unusual vibration, it must be reconditioned or changed immediately.	5	 			
	Total	60				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.21. Track tension: check/adjust



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	<p>Note: The track adjusting mechanism is under very high-pressure. Never release pressure too suddenly. The track tension grease valve should never be backed off more than one (1) complete turn from the tightened down position</p> <p>Under normal usage, the track shoe link pins and bushing wear- out and reducing the track tension</p>					
1	Track tension is checked by jacking up one side of the truck side. Place blocking under frame while taking measurement. Turn the track backward 1-2 turns	10	wrench	1-set		
			mechanical jack	1-set		
			jack-up stand	1-set		
2	Clean off the tracks before checking the clearance. Measurement can be inaccurate if there is too much mud or dirt or other material in the track assembly	10				
3	Measuring the distance between the bottom of the side frame and the top of the lowest crawler shoe. Recommended tension for operation over most types of terrain is 290 - 310 mm (11.42 - 12.20 inches)	5	tape measure	1-set		
4	Track tension adjustments are made thru the grease fitting located in the middle of each side frame. Adding grease increases the length of an adjustment cylinder. The longer the adjustment cylinder, the greater the pressure on the tension spring pushing the track idler wheel outward.	15	grease gun	1-set	multi-purpose grease	500 gm
					rag	1/4 kg
5	If there is not enough slack or clearance in the tracks and the adjustment is too tight, the idler wheel and adjusting cylinder can be retracted by bleeding off grease thru hole in valve by loosening valve slowly. When grease starts to leak out, stop loosening it.	15	 			
6	After track is adjusted by loosening valve, be sure to tighten valve to 14 kg.m or 101 ft. lb.	5				
	Total	60				

6.0. Crawler Tractor

DPWH Property Code: L1

Maintenance Activity: PM 4

6.22. Air conditioner refrigerant: check

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Note: Inhaling air conditioner refrigerant gas thru a lit cigarette or other smoking method or inhaling fumes released from a flame contacting refrigerant gas can cause bodily harm or death					
1	Run engine at about 1,800 rpm. Operate for a minimum of ten (10) minutes to stabilize the air conditioning system	10				
2	Press the "HI" fan speed switch to set maximum airflow	1				
	Put the temperature control switch in maximum cooling position					
	Press the "Internal Air Circulation switch					
3	Compare the flow of bubbles in the sight glass of receiver dryer in the following table:	1				
4	Amount of refrigerant: Almost clear. Any bubbles disappear. Normal; No bubbles are seen. High. Withdraw the system with the correct amount of HFC 134a A flow of bubbles is visible. Low. Charge the system with the correct amount of HFC 134a	8			rag	1/4 kg
	Important: Overfilling refrigerant can cause dangerous high-pressure and poor cooling action; and low refrigerant level can cause compressor damage					
	Total	20				




7.0. FRONT-END LOADER (L2)

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 2

7.1. Engine oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Park the unit on a firm level ground					
1	Open access	1				
2	Put a suitable container under the drain plug at the bottom of the oil pan	2	drain pan	1-pc		
3	Remove the oil filler cap and oil filter	5	oil filter wrench	1-pc		
4	Remove the drain plug to drain the oil into a container Note: While draining, clean the air filter	20	wrench	1-pc		
5	When engine oil drops intermittently, apply compressed air into the filler hole to hasten draining	9			rag	1-pc
6	Install drain plug and oil filter	8			oil filter	1-pc
7	Fill new engine oil into the filler hole with the specified viscosity/SAE No	10			engine oil	as stated
8	Run the engine and check for leaks	5				
	Total	60				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 2

7.2.Engine oil filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Replace the oil filter every time the oil is changed Remove the oil filter	3	filter wrench	1-pc		
2	Clean the filter housing base and apply a light coat of engine oil to the gasket of the new filter	2			new oil filter	1-pc
					engine oil	as stated
					rag	1/4 kg
3	Fill the new filter with the specified engine oil	1				
4	Screw on the new filter by hand until the gasket just touches the sealing surface. Tighten the filter a further 1/2 turn	3				
5	Start the engine and check that the gasket is sealed. If not, remove the filter and check the sealing surface	3				
	Note: It is important that the new filter is filled with the prescribed engine oil before it is installed. This is to ensure lubrication of the engine immediately after starting					
	Total	12				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 2

7.3. Primary Air filter: clean and replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Do not, under any circumstances, run the engine without air filter or with a damaged one. The degree of engine wear depends largely on the cleanliness of the induction air.					
1	Open the access door at the rear of the cabin	1				
2	Remove the evacuator valve and air cleaner cover	2				
3	Press with both thumbs on primary filter at the same time as you pull it out. This is to prevent the secondary filter from coming out together with the primary filter.	2				
4	Carefully tap the end of the air filter against a soft and clean surface	5				
5	Use clean and dry compressed air, blow the filter from the inside along the folds	5			compressed air	as stated
6	If there is the smallest hole, scratch, crack or other damage, the filter must be discarded	1			rag	1/4 kg
7	Install the primary air filter and the cover	4				
	Total	20				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 2

7.4. Hydraulic drain filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	5	wrench	1-pc	 rag	1/4 kg
			screw driver	1-pc		
			plier	1-pc		
4	Place a container under the drain filter and turn the filter counter clockwise to remove it.	5			drain pan	1-pc
5	Fill the new filter with oil, thinly coat O-ring with oil.	1			new filter	1-pc
					hydraulic oil	as stated
6	Install the new filter	7				
	Total	20				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 2

7.5. Arm and Front Attachments Pins: greasing






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Wipe off the grease nipples and the grease gun before greasing, to avoid introducing sand and dirt particles with the grease.					
1	Position the machine on a firm, level ground. Lower the front attachment to the ground and shut down the engine.	2				
2	Press the grease fitting and inject grease with the use of grease gun on the marked points: * Boom cylinder head pin * Boom foot pin * Boom cylinder rod pin * Arm cylinder head pin * Boom arm joint pin * Arm cylinder rod pin * Bucket cylinder head pin	15	grease gun	1-set	multi-purpose grease	500 gm
			wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	After injection, clean off the old grease that has been purged.	3				
	Note: If the machine has been running or working in water the front attachment should be greased on a 10-hour/ daily basis					
	Total	20				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 2

7.6. Engine fan belt: check/replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	<p>Note: A loose fan belt can cause engine overheating, poor charging, and premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing or belt.</p> <p>With the engine shut off, and the starter switch is in the "OFF" position and the controls are tagged, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex approximately 10 mm (0.4 in.)</p>	5	 			
2	To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.	10	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	<p>Replace the belts if it is badly worn, greasy and severely cracked.</p> <p>Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable and if it is frayed or has pieces of material missing.</p>	5				
4	Install the new belts, make sure all pulley must be aligned. The grooves, bearings, shafts are in working order. Brackets are securely clamped. If damaged, replace.	15	 		fan belt	1-pc
5	Repeat activity nos. 1 and 2	15				
	Reminder: Check/adjust the tension of new belts at 50 hours intervals until tension is stabilized and thereafter, every 250 hours.					
	Total	50				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 2

7.7. Axle carrier oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	2				
2	Remove the filling and level checking plug (upper position). If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 2

7.8. Axle Hub oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	2				
2	Position the filling and level checking plug on a horizontal axis (position of 3 o'clock) and remove the plug. If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 2

7.9. Front attachments, cylinders, pins and ball joints: greasing






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Wipe off the grease nipples and the grease gun before greasing, to avoid introducing sand and dirt particles with the grease.					
1	Position the machine on a firm, level ground. Rest the blade on the ground and shut down the engine.	5				
2	Press the grease fitting and inject grease with the use of grease gun on the marked points:	25	grease gun	1-set	multi-purpose grease	500 gm
	Leaning cylinder pin		wrench	1-pc	rag	1/4 kg
	Tie rod		screw driver	1-pc		
	Knuckle bracket king pin					
	Leaning pin					
	Steering cylinder					
	Front axle center pin					
	Drawbar ball joint					
	Scarifier ball joint					
	Scarifier cylinder pin					
	Blade lift cylinder yoke					
	Blade lift cylinder ball joint					
	Drawbar side shift cylinder ball					
	Bank control guide					
	Articulation center pin					
	Articulation cylinder pin					
3	After injection, clean off the old grease that has been purged.	10				
	Total	40				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 3

7.10. Fuel filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Exchange filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke.	2			container	1/2 pail
	Locate fuel filter inside engine compartment. Position a small container under the filter.				rag	1/4 kg
2	Unscrew fuel filter from head assembly. Discard fuel filter properly.	3	wrench	1-pc		
			screw driver	1-pc		
3	After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench. Note: Coat fuel filter gasket with fuel and fill fuel filter with clean fuel. This will help reduce fuel system priming.	5	filter wrench	1-pc	new fuel filter	1-pc
					fuel oil	as stated
4	If the fuel filter has been replaced, air may need to be bleed using the following <u>FUEL SYSTEM PRIMING</u> : Loosen plug on top of the fuel filter head.	3				
5	Unscrew and pump the hand operated priming pump by the fuel injection pump. Pump priming pump until fuel is present at plug hole in fuel filter head.	5	 			
6	Tighten plug in fuel filter head.	1				
7	Continue to pump the priming pump until a strong resistance is felt. Screw the priming pump knob back into housing to lock the plunger.	3				
8	Start engine and look for signs of leaks. Repeat procedure if necessary.	3				
	Total	25				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 3

7.11. Controls: check/adjust/lubricate






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Controls for: bucket; tilting; tandem;					
1	Lubricate all joints and linkages	20	oiler	1-pc	multi-purpose grease	500 gm
			grease gun	1-set	lubricating oil	as stated
			wrench	1-pc	rag	1/4 kg
2	Check and adjust clearance	5				
3	Clean off surplus grease and oil completely.	5				
	Total	30				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 3

7.12. Air-conditioning system: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: When a leak occurs, dirt will accumulate in the area where the leak is.					
1	All service and inspection of air-conditioning system should be performed with the starter switch in the "O" (Off) position.	1				
2	Check the hoses for damage and cracks.	1				
3	Inspect the condenser for dust and debris. Clean if necessary.	2			detergent	as
					water	stated
					rag	1/4 kg
4	Push the "A/C" switch on in order to energize the magnetic clutch. Check the magnetic clutch for dirt and interference.	2				
5	At correct belt tension, it should be possible to depress the belt approximately 10 mm (0.4 in.). Adjust if necessary.	2	wrench 	1-pc		
			screw driver	1-pc		
6	If the unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into the operator's cabin, clean the air-conditioning outer and inner filters.	5				
7	Open the door in the left front of the machine, then remove the cover by loosening the four wing bolts.	5				
8	Remove the outer filter, then the inner filter and inspect for any damage. If the filter is damaged replace with a new one.	2				
9	Use compressed air to clean the filters. If the filter is very dirty, use a mild soap or detergent and water to clean it.	5			compressed air	as stated
10	If water was used, be certain the filters are completely dry. Install the filters and assemble it in reverse order.	5				
	Total	30				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 3

7.13. Alternator assembly: check/inspect





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	2	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the alternator assembly	30				
4	Overhaul and clean	40			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease, bushing for wear. Replace if necessary.	5				
6	Assemble the alternator and install. If possible, check the alternator ratings on bench testing machine.	30	bench testing machine	1-set		
7	Check the alternator belt tension by pressing downwards on the belt, midway between the fan pulley and alternator pulley.	5				
8	Adjust the belt tension by loosening the alternator adjustment plate bolts. The belt should flex approximately 10 mm (0.4 in.) Retighten the bolts.	5				
9	Run the engine and check for any jarring noise and excessive vibration.	2				
	Total	120				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 3

7.14. Starting motor: check/inspect



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	1	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the starting motor	30				
4	Overhaul and clean	25			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease; bushing for wear. Replace if necessary.	1				
6	Assemble the starting motor and install. If possible, check the starting motor ratings on bench testing machine.	30	bench testing machine	1-set		
9	Run the engine and check for any jarring noise and vibration.	2				
	Total	90				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 3

7.15. Water separator element: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Turn priming pump counterclockwise to unlock the plunger then turn shut-off valve clockwise 90 degrees	1	wrench	1-pc		
			 screw driver	1-pc		
			plier	1-pc		
2	Place a suitable sized container under the drain hose	1			drain pan	1-pc
					rag	1/4 kg
3	Open drain valve and drain the fuel from the water separator, afterwards close the drain valve	5				
4	Disconnect sensor connector	1				
5	Remove bowl assembly and set it aside for installation and remove filter element	5	filter wrench	1-pc		
6	Clean the inside surface of the filter head and of the bowl; check the condition of the O-ring. Replace the O-ring if damaged	30				
7	Apply a small amount of fuel to the gasket of the new filter; install the new filter by hand until it contacts the mounting surface. Tighten the filter	30			new filter	1-pc
					fuel oil	as stated
8	Install bowl assembly; reconnect sensor connector	5				
9	Turn shut-off valve counterclockwise 90 degrees	2				
10	Bleed the system	10				
	Total	90				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.16. Hydraulic oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Warning! Take care when changing the oil. Hot oil can cause burns on unprotected skin					
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	3	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc	rag	1/4 kg
4	Open the cover after removing the screws and remove O-ring then pull out the strainer.	20				
6	Place a suitable container under the drain plug of hydraulic tank	1			drain pan	1-pc
7	Remove the drain plug	3				
8	Drain the oil into the container. Wait till the last drop of oil for few minutes	20				
9	Reinstall the drain plug	5				
10	Clean the magnetic rings of strainer thoroughly. Check O-ring and if damaged, replace it with a new one and reinstall the strainer.	5			compressed air	as stated
11	Refill oil and reinstall the cover	20			hydraulic oil	as stated
12	Check the oil in the sight gauge.	1				
13	Perform test run to check for any leaks	10				
	Total	90				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.17. Hydraulic pilot filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	2				
4	Place a container under the pilot filter.	1			drain pan	1-pc
5	Unscrew/remove the filter bowl or canister, O-ring and inner element. Note: The bowl/canister will be filled with oil. Use caution when removing this assembly.	5	wrench	1-pc	rag	1/4 kg
			 plier	1-pc		
6	Install a new inner filter element and O-ring. Apply a small amount of oil around the entire O-ring.	5			pilot filter element	1-pc
					o-ring	1-pc
					hydraulic oil	as stated
7	Reinstall the filter bowl/canister.	2				
8	After changing the pilot filter element, vent air from pump and check level of hydraulic oil tank.	3				
	Total	20				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.18. Transfer gearbox oil: change




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case could eject the oil and plug. Put a suitable sized container , above 3 liters, under the drain plug of transfer gearbox to receive the oil.	15			drain pan	1-pc
4	Loosen the drain plug slowly, discharge the oil completely.	15	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	Tighten the drain plug again and remove the filling plug and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil level is normal. Then install the filling plug.	3			engine oil	as stated
6	Check the oil level once again after a driving time of about 5 minutes. If necessary, refill the oil.	5				
	Total	40				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.19. Transfer gearbox: air bleeding



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower bucket to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	<u>Note:</u> After initial assembly of the machine or disconnecting high/low speed pressure line (from pump to transfer gearbox) and remounting, bleed the air from the transfer gearbox before travelling the machine. Releaser the parking brake.	15				
4	Set the gear speed change lever to 2nd. Open bleeder of the brake and bleed it for approximately 20 seconds.	3	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	When the brake is bled the first time, additionally open also bleeder of the emergency actuating device to bring it into its initial position. In this case no oil flows out.	3				
6	Close both bleeders.	1				
7	Set the gear speed change lever to 1st (low speed). Open bleeder of the clutch and bleed it for approximately 20 seconds.	2				
8	Close bleeder of the clutch.	1				
9	Repeat bleeding the brake and clutch 2 times each for approximately 20 seconds. At the last bleeding procedure no air bubbles are allowed to be visible in the oil anymore.	10				
10	Check all screws connections for leaks. <u>Important:</u> If the air in the transfer gearbox is not vented out, a serious fault may develop, such as damage of the clutch in the transfer gearbox may occur.	3				
	Total	40				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.20. Axle Carrier oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	5				
2	Put a suitable container under the drain plug (lower position) of axle carrier to receive the oil.	2			drain pan	1-pc
3	Loosen the drain plug, then the filling plug (upper position) and discharge the oil completely.	5	wrench	1-pc	rag	1/4 kg
4	Tighten the drain plug and supply new oil thru the filling plug. If the oil is about to overflow from the hole, the oil level is normal.	5			gear oil	as stated
5	Install the filling plug and tighten securely.	3				
	Total	20				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.21. Axle Hub oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	5				
2	Put a suitable sized container under the drain plug of axle carrier to receive the oil.	1			drain pan	1-pc
					rag	1/4 kg
3	Position the drain plug on the vertical axis (position of 6 o'clock).	1				
4	Loosen the drain plug and filling plug to discharge the oil completely.	5	wrench	1-pc	gear oil	as stated
5	Tighten the drain plug again and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil is normal.	5				
6	Install filling plug and tighten securely.	3				
	Total	20				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.22. Hydraulic System: venting and priming

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: If pump is run without sufficient oil in the main hydraulic pump, damage can occur. Always vent pump of air after draining hydraulic system. With the engine stopped, remove vent plug to see if any oil is present.	3	wrench 	1-pc	rag	1/4 kg
2	If oil is not present, fill pump with oil thru port.	5			hydraulic oil	as stated
3	Install vent plug first.	2				
4	Start engine and run it for several minutes at low idle engine speed. This will pressurize the hydraulic oil tank and system.	5	 			
5	Slowly loosen vent plug several turns, until hydraulic oil flows out of plug. This shows that air has been released. Tighten the plug.	5				
	Total	20				



7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.23. A. Check/adjust engine valve clearance

B. Check/retight cylinder head bolt





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Open access	1				
2	Remove parts/accessories to give way for the adjustment of engine valve	5	flat screw driver	1-pc		
			cross screw driver	1-pc		
			plier	1-pc		
			combination wrench	1-pc		
3	Remove valve cover	5			rag	1/4 kg
4	Check/untorque cylinder head bolt	15				
5	Adjust valve clearance	30	feeler gauge	1-set		
6	After valve clearance adjustment, repeat the procedure in reverse order	25			sealant	1-tube
					gasket	1-set
7	Start the engine and check for leak and any distorting noise	5				
	Note: Follow procedure of engine valve clearance/adjustment according to manufacturer's guide and standards					
	Total	86				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.24. Turbocharger: check/clean



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Leave the engine running at low idling speed for at least a minute after start and a few minutes before it is stopped. This is to safeguard the lubrication of the turbocharger.					
1	Remove the oil filler pipe and drain pipe, then remove the intake air pipe connector and blower housing so that the blower impeller can be seen.	10	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	NOTE: excessive carbon or oil sludge adhering to turbocharger blower may lead to performance deterioration and possible damage. Using light oil as a cleaning agent, remove the carbon, sludge, and other dirt from the blower impeller.	5			light oil	as stated
					rag	1/4 kg
3	Pour in light oil thru the turbocharger oil filler and rotate the blower impeller several times to wash out the sludge.	5				
4	Rotate the impeller by hand at least one turn at speed to check that there is contact noise or catching inside. If the impeller does not turn smoothly, contact the equipment manufacturer for repair or replacement.	10				
5	If there is no abnormality, dry off the light oil with compressed air after inspection, then add engine oil.	5			compressed air	as stated
6	Reassemble in reverse order.	20				
7	Run the engine and if any jarring noises be heard and shows unusual vibration, it must be reconditioned or changed immediately.	5				
						
	Total	60				

7.0. Front-end Loader

DPWH Property Code: L2

Maintenance Activity: PM 4

7.25. Air conditioner refrigerant: check

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Note: Inhaling air conditioner refrigerant gas thru a lit cigarette or other smoking method or inhaling fumes released from a flame contacting refrigerant gas can cause bodily harm or death					
1	Run engine at about 1,800 rpm. Operate for a minimum of ten (10) minutes to stabilize the air conditioning system	10				
2	Press the "HI" fan speed switch to set maximum airflow	1				
	Put the temperature control switch in maximum cooling position					
	Press the "Internal Air Circulation switch					
3	Compare the flow of bubbles in the sight glass of receiver dryer in the following table:	1				
4	Amount of refrigerant: Almost clear. Any bubbles disappear. Normal; No bubbles are seen. High. Withdraw the system with the correct amount of HFC 134a A flow of bubbles is visible. Low. Charge the system with the correct amount of HFC 134a	8			rag	1/4 kg
	Important: Overfilling refrigerant can cause dangerous high-pressure and poor cooling action; and low refrigerant level can cause compressor damage					
	Total	20				




8.0. ROAD GRADER (N1)

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 2

8.1. Engine oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Park the unit on a firm level ground					
1	Open access	1				
2	Put a suitable container under the drain plug at the bottom of the oil pan	2	drain pan	1-pc		
3	Remove the oil filler cap and oil filter	5	oil filter wrench	1-pc		
4	Remove the drain plug to drain the oil into a container Note: While draining, clean the air filter	20	wrench	1-pc		
5	When engine oil drops intermittently, apply compressed air into the filler hole to hasten draining	9			rag	1-pc
6	Install drain plug and oil filter	8			oil filter	1-pc
7	Fill new engine oil into the filler hole with the specified viscosity/SAE No	10			engine oil	as stated
8	Run the engine and check for leaks	5				
	Total	60				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 2

8.2. Engine oil filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Replace the oil filter every time the oil is changed Remove the oil filter	3	filter wrench	1-pc		
2	Clean the filter housing base and apply a light coat of engine oil to the gasket of the new filter	2			new oil filter	1-pc
					engine oil	as stated
					rag	1/4 kg
3	Fill the new filter with the specified engine oil	1				
4	Screw on the new filter by hand until the gasket just touches the sealing surface. Tighten the filter a further 1/2 turn	3				
5	Start the engine and check that the gasket is sealed. If not, remove the filter and check the sealing surface	3				
	Note: It is important that the new filter is filled with the prescribed engine oil before it is installed. This is to ensure lubrication of the engine immediately after starting					
	Total	12				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 2

8.3. Primary Air filter: clean and replace




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Do not, under any circumstances, run the engine without air filter or with a damaged one. The degree of engine wear depends largely on the cleanliness of the induction air.					
1	Open the access door at the rear of the cabin	1				
2	Remove the evacuator valve and air cleaner cover	2				
3	Press with both thumbs on primary filter at the same time as you pull it out. This is to prevent the secondary filter from coming out together with the primary filter.	2				
4	Carefully tap the end of the air filter against a soft and clean surface	5				
5	Use clean and dry compressed air, blow the filter from the inside along the folds	5			compressed air	as stated
6	If there is the smallest hole, scratch, crack or other damage, the filter must be discarded	1			rag	1/4 kg
7	Install the primary air filter and the cover	4				
	Total	20				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 2

8.4. Hydraulic drain filter: replace






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower blade to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	5	wrench	1-pc	 rag	1/4 kg
			screw driver	1-pc		
			plier	1-pc		
4	Place a container under the drain filter and turn the filter counter clockwise to remove it.	5			drain pan	1-pc
5	Fill the new filter with oil, thinly coat O-ring with oil.	1			new filter	1-pc
					hydraulic oil	as stated
6	Install the new filter	7				
	Total	20				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 2

8.5. Engine fan belt: check/replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	<p>Note: A loose fan belt can cause engine overheating, poor charging, and premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing or belt.</p> <p>With the engine shut off, and the starter switch is in the "OFF" position and the controls are tagged, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex approximately 10 mm (0.4 in.)</p>	5	 			
2	To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.	10	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	<p>Replace the belts if it is badly worn, greasy and severely cracked.</p> <p>Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable and if it is frayed or has pieces of material missing.</p>	5				
4	Install the new belts, make sure all pulley must be aligned. The grooves, bearings, shafts are in working order. Brackets are securely clamped. If damaged, replace.	15	 		fan belt	1-pc
5	Repeat activity nos. 1 and 2	15				
	Reminder: Check/adjust the tension of new belts at 50 hours intervals until tension is stabilized and thereafter, every 250 hours.					
	Total	50				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 2

8.6. Axle carrier oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	2				
2	Remove the filling and level checking plug (upper position). If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 2

8.7. Axle Hub oil level: check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	2				
2	Position the filling and level checking plug on a horizontal axis (position of 3 o'clock) and remove the plug. If the oil is about to overflow from the hole, the oil level is normal.	3	 wrench	1-pc	rag	1/4 kg
3	If the oil is low, refill to the proper level. Then install the filling plug.	5			gear oil	as stated
	Total	10				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 2

8.8. Front attachments, cylinders, pins and ball joints: greasing






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Wipe off the grease nipples and the grease gun before greasing, to avoid introducing sand and dirt particles with the grease.					
1	Position the machine on a firm, level ground. Rest the blade on the ground and shut down the engine.	5				
2	Press the grease fitting and inject grease with the use of grease gun on the marked points:	25	grease gun	1-set	multi-purpose grease	500 gm
	Leaning cylinder pin		wrench	1-pc	rag	1/4 kg
	Tie rod		screw driver	1-pc		
	Knuckle bracket king pin					
	Leaning pin					
	Steering cylinder					
	Front axle center pin					
	Drawbar ball joint					
	Scarifier ball joint					
	Scarifier cylinder pin					
	Blade lift cylinder yoke					
	Blade lift cylinder ball joint					
	Drawbar side shift cylinder ball					
	Bank control guide					
	Articulation center pin					
	Articulation cylinder pin					
3	After injection, clean off the old grease that has been purged.	10				
	Total	40				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 3

8.9. Fuel filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Exchange filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke.	2			container	1/2 pail
	Locate fuel filter inside engine compartment. Position a small container under the filter.				rag	1/4 kg
2	Unscrew fuel filter from head assembly. Discard fuel filter properly.	3	wrench	1-pc		
			screw driver	1-pc		
3	After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench. Note: Coat fuel filter gasket with fuel and fill fuel filter with clean fuel. This will help reduce fuel system priming.	5	filter wrench	1-pc	new fuel filter	1-pc
					fuel oil	as stated
4	If the fuel filter has been replaced, air may need to be bled using the following <u>FUEL SYSTEM PRIMING</u> : Loosen plug on top of the fuel filter head.	3				
5	Unscrew and pump the hand operated priming pump by the fuel injection pump. Pump priming pump until fuel is present at plug hole in fuel filter head.	5	 			
6	Tighten plug in fuel filter head.	1				
7	Continue to pump the priming pump until a strong resistance is felt. Screw the priming pump knob back into housing to lock the plunger.	3				
8	Start engine and look for signs of leaks. Repeat procedure if necessary.	3				
	Total	25				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 3

8.10. Controls: check/adjust/lubricate






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Controls for: bucket; tilting; tandem;					
1	Lubricate all joints and linkages	20	oiler	1-pc	multi-purpose grease	500 gm
			grease gun	1-set	lubricating oil	as stated
			wrench	1-pc	rag	1/4 kg
2	Check and adjust clearance	5				
3	Clean off surplus grease and oil completely.	5				
	Total	30				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 3

8.11. Air-conditioning system: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: When a leak occurs, dirt will accumulate in the area where the leak is.					
1	All service and inspection of air-conditioning system should be performed with the starter switch in the "O" (Off) position.	1				
2	Check the hoses for damage and cracks.	1				
3	Inspect the condenser for dust and debris. Clean if necessary.	2			detergent	as
					water	stated
					rag	1/4 kg
4	Push the "A/C" switch on in order to energize the magnetic clutch. Check the magnetic clutch for dirt and interference.	2				
5	At correct belt tension, it should be possible to depress the belt approximately 10 mm (0.4 in.). Adjust if necessary.	2	wrench 	1-pc		
			screw driver	1-pc		
6	If the unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into the operator's cabin, clean the air-conditioning outer and inner filters.	5				
7	Open the door in the left front of the machine, then remove the cover by loosening the four wing bolts.	5				
8	Remove the outer filter, then the inner filter and inspect for any damage. If the filter is damaged replace with a new one.	2				
9	Use compressed air to clean the filters. If the filter is very dirty, use a mild soap or detergent and water to clean it.	5			compressed air	as stated
10	If water was used, be certain the filters are completely dry. Install the filters and assemble it in reverse order.	5				
	Total	30				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 3

8.12. Alternator assembly: check/inspect





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	2	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the alternator assembly	30				
4	Overhaul and clean	40			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease, bushing for wear. Replace if necessary.	5				
6	Assemble the alternator and install. If possible, check the alternator ratings on bench testing machine.	30	bench testing machine	1-set		
7	Check the alternator belt tension by pressing downwards on the belt, midway between the fan pulley and alternator pulley.	5				
8	Adjust the belt tension by loosening the alternator adjustment plate bolts. The belt should flex approximately 10 mm (0.4 in.) Retighten the bolts.	5				
9	Run the engine and check for any jarring noise and excessive vibration.	2				
	Total	120				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 3

8.13. Starting motor: check/inspect



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	1	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the starting motor	30				
4	Overhaul and clean	25			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease; bushing for wear. Replace if necessary.	1				
6	Assemble the starting motor and install. If possible, check the starting motor ratings on bench testing machine.	30	bench testing machine	1-set		
9	Run the engine and check for any jarring noise and vibration.	2				
	Total	90				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 3

8.14. Water separator element: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Turn priming pump counterclockwise to unlock the plunger then turn shut-off valve clockwise 90 degrees	1	wrench	1-pc		
			 screw driver	1-pc		
			plier	1-pc		
2	Place a suitable sized container under the drain hose	1			drain pan	1-pc
					rag	1/4 kg
3	Open drain valve and drain the fuel from the water separator, afterwards close the drain valve	5				
4	Disconnect sensor connector	1				
5	Remove bowl assembly and set it aside for installation and remove filter element	5	filter wrench	1-pc		
6	Clean the inside surface of the filter head and of the bowl; check the condition of the O-ring. Replace the O-ring if damaged	30				
7	Apply a small amount of fuel to the gasket of the new filter; install the new filter by hand until it contacts the mounting surface. Tighten the filter	30			new filter	1-pc
					fuel oil	as stated
8	Install bowl assembly; reconnect sensor connector	5				
9	Turn shut-off valve counterclockwise 90 degrees	2				
10	Bleed the system	10				
	Total	90				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.15. Hydraulic oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Warning! Take care when changing the oil. Hot oil can cause burns on unprotected skin					
1	Park the equipment on a firm, level ground	1				
2	Lower blade to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	3	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc	rag	1/4 kg
4	Open the cover after removing the screws and remove O-ring then pull out the strainer.	20				
6	Place a suitable container under the drain plug of hydraulic tank	1			drain pan	1-pc
7	Remove the drain plug	3				
8	Drain the oil into the container. Wait till the last drop of oil for few minutes	20				
9	Reinstall the drain plug	5				
10	Clean the magnetic rings of strainer thoroughly. Check O-ring and if damaged, replace it with a new one and reinstall the strainer.	5			compressed air	as stated
11	Refill oil and reinstall the cover	20			hydraulic oil	as stated
12	Check the oil in the sight gauge.	1				
13	Perform test run to check for any leaks	10				
	Total	90				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.16. Hydraulic pilot filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower blade to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	2				
4	Place a container under the pilot filter.	1			drain pan	1-pc
5	Unscrew/remove the filter bowl or canister, O-ring and inner element. Note: The bowl/canister will be filled with oil. Use caution when removing this assembly.	5	wrench	1-pc	rag	1/4 kg
			 plier	1-pc		
6	Install a new inner filter element and O-ring. Apply a small amount of oil around the entire O-ring.	5			pilot filter element	1-pc
					o-ring	1-pc
					hydraulic oil	as stated
7	Reinstall the filter bowl/canister.	2				
8	After changing the pilot filter element, vent air from pump and check level of hydraulic oil tank.	3				
	Total	20				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.17. Transfer gearbox oil: change




Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower blade to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case could eject the oil and plug. Put a suitable sized container , above 3 liters, under the drain plug of transfer gearbox to receive the oil.	15			drain pan	1-pc
4	Loosen the drain plug slowly, discharge the oil completely.	15	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	Tighten the drain plug again and remove the filling plug and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil level is normal. Then install the filling plug.	3			engine oil	as stated
6	Check the oil level once again after a driving time of about 5 minutes. If necessary, refill the oil.	5				
	Total	40				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.18. Transfer gearbox: air bleeding



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower blade to the ground, move the control lock out lever down to lock the hydraulic system securely and shut down the engine	1				
3	<u>Note:</u> After initial assembly of the machine or disconnecting high/low speed pressure line (from pump to transfer gearbox) and remounting, bleed the air from the transfer gearbox before travelling the machine. Releaser the parking brake.	15				
4	Set the gear speed change lever to 2nd. Open bleeder of the brake and bleed it for approximately 20 seconds.	3	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
5	When the brake is bled the first time, additionally open also bleeder of the emergency actuating device to bring it into its initial position. In this case no oil flows out.	3				
6	Close both bleeders.	1				
7	Set the gear speed change lever to 1st (low speed). Open bleeder of the clutch and bleed it for approximately 20 seconds.	2				
8	Close bleeder of the clutch.	1				
9	Repeat bleeding the brake and clutch 2 times each for approximately 20 seconds. At the last bleeding procedure no air bubbles are allowed to be visible in the oil anymore.	10				
10	Check all screws connections for leaks. <u>Important:</u> If the air in the transfer gearbox is not vented out, a serious fault may develop, such as damage of the clutch in the transfer gearbox may occur.	3				
	Total	40				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.19. Axle Carrier oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly.	5				
2	Put a suitable container under the drain plug (lower position) of axle carrier to receive the oil.	2			drain pan	1-pc
3	Loosen the drain plug, then the filling plug (upper position) and discharge the oil completely.	5	wrench	1-pc	rag	1/4 kg
4	Tighten the drain plug and supply new oil thru the filling plug. If the oil is about to overflow from the hole, the oil level is normal.	5			gear oil	as stated
5	Install the filling plug and tighten securely.	3				
	Total	20				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.20. Axle Hub oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Immediately after operating the machine, the oil is hot. Allow the oil to cool. Residual pressure in the transfer case, can eject the oil and plug. Loosen the plug slowly	5				
2	Put a suitable sized container under the drain plug of axle carrier to receive the oil.	1			drain pan	1-pc
					rag	1/4 kg
3	Position the drain plug on the vertical axis (position of 6 o'clock).	1				
4	Loosen the drain plug and filling plug to discharge the oil completely.	5	wrench	1-pc	gear oil	as stated
5	Tighten the drain plug again and supply oil thru the filling hole. If the oil is about to overflow from the hole, the oil is normal.	5				
6	Install filling plug and tighten securely.	3				
	Total	20				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.21. Hydraulic System: venting and priming

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: If pump is run without sufficient oil in the main hydraulic pump, damage can occur. Always vent pump of air after draining hydraulic system. With the engine stopped, remove vent plug to see if any oil is present.	3	wrench 	1-pc	rag	1/4 kg
2	If oil is not present, fill pump with oil thru port.	5			hydraulic oil	as stated
3	Install vent plug first.	2				
4	Start engine and run it for several minutes at low idle engine speed. This will pressurize the hydraulic oil tank and system.	5	 			
5	Slowly loosen vent plug several turns, until hydraulic oil flows out of plug. This shows that air has been released. Tighten the plug.	5				
	Total	20				



8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.22. A. Check/adjust engine valve clearance

B. Check/retight cylinder head bolt






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Open access	1				
2	Remove parts/accessories to give way for the adjustment of engine valve	5	flat screw driver	1-pc		
			cross screw driver	1-pc		
			plier	1-pc		
			combination wrench	1-pc		
3	Remove valve cover	5			rag	1/4 kg
4	Check/untorque cylinder head bolt	15				
5	Adjust valve clearance	30	feeler gauge	1-set		
6	After valve clearance adjustment, repeat the procedure in reverse order	25			sealant	1-tube
					gasket	1-set
7	Start the engine and check for leak and any distorting noise	5				
	Note: Follow procedure of engine valve clearance/adjustment according to manufacturer's guide and standards					
	Total	86				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.23. Turbocharger: check/clean



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Leave the engine running at low idling speed for at least a minute after start and a few minutes before it is stopped. This is to safeguard the lubrication of the turbocharger.					
1	Remove the oil filler pipe and drain pipe, then remove the intake air pipe connector and blower housing so that the blower impeller can be seen.	10	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	NOTE: excessive carbon or oil sludge adhering to turbocharger blower may lead to performance deterioration and possible damage. Using light oil as a cleaning agent, remove the carbon, sludge, and other dirt from the blower impeller.	5			light oil	as stated
					rag	1/4 kg
3	Pour in light oil thru the turbocharger oil filler and rotate the blower impeller several times to wash out the sludge.	5				
4	Rotate the impeller by hand at least one turn at speed to check that there is contact noise or catching inside. If the impeller does not turn smoothly, contact the equipment manufacturer for repair or replacement.	10				
5	If there is no abnormality, dry off the light oil with compressed air after inspection, then add engine oil.	5			compressed air	as stated
6	Reassemble in reverse order.	20				
7	Run the engine and if any jarring noises be heard and shows unusual vibration, it must be reconditioned or changed immediately.	5	 			
	Total	60				

8.0. Road Grader

DPWH Property Code: N1

Maintenance Activity: PM 4

8.24. Air conditioner refrigerant: check

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Note: Inhaling air conditioner refrigerant gas thru a lit cigarette or other smoking method or inhaling fumes released from a flame contacting refrigerant gas can cause bodily harm or death					
1	Run engine at about 1,800 rpm. Operate for a minimum of ten (10) minutes to stabilize the air conditioning system	10				
2	Press the "HI" fan speed switch to set maximum airflow	1				
	Put the temperature control switch in maximum cooling position					
	Press the "Internal Air Circulation switch					
3	Compare the flow of bubbles in the sight glass of receiver dryer in the following table:	1				
4	Amount of refrigerant: Almost clear. Any bubbles disappear. Normal; No bubbles are seen. High. Withdraw the system with the correct amount of HFC 134a A flow of bubbles is visible. Low. Charge the system with the correct amount of HFC 134a	8			rag	1/4 kg
	Important: Overfilling refrigerant can cause dangerous high-pressure and poor cooling action; and low refrigerant level can cause compressor damage					
	Total	20				




9.0. VIBRATORY ROLLER (Z18)

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 2

9.1. Engine oil: change



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Park the unit on a firm level ground					
1	Open access	1				
2	Put a suitable container under the drain plug at the bottom of the oil pan	2	drain pan	1-pc		
3	Remove the oil filler cap and oil filter	5	oil filter wrench	1-pc		
4	Remove the drain plug to drain the oil into a container Note: While draining, clean the air filter	20	wrench	1-pc		
5	When engine oil drops intermittently, apply compressed air into the filler hole to hasten draining	9			rag	1-pc
6	Install drain plug and oil filter	8			oil filter	1-pc
7	Fill new engine oil into the filler hole with the specified viscosity/SAE No	10			engine oil	as stated
8	Run the engine and check for leaks	5				
	Total	60				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 2

9.2. Engine oil filter: replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Replace the oil filter every time the oil is changed Remove the oil filter	3	filter wrench	1-pc		
2	Clean the filter housing base and apply a light coat of engine oil to the gasket of the new filter	2			new oil filter	1-pc
					engine oil	as stated
					rag	1/4 kg
3	Fill the new filter with the specified engine oil	1				
4	Screw on the new filter by hand until the gasket just touches the sealing surface. Tighten the filter a further 1/2 turn	3				
5	Start the engine and check that the gasket is sealed. If not, remove the filter and check the sealing surface	3				
	Note: It is important that the new filter is filled with the prescribed engine oil before it is installed. This is to ensure lubrication of the engine immediately after starting					
	Total	12				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 2

9.3. Primary Air filter: clean and replace



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Do not, under any circumstances, run the engine without air filter or with a damaged one. The degree of engine wear depends largely on the cleanliness of the induction air.					
1	Open the access door at the rear of the cabin	1				
2	Remove the evacuator valve and air cleaner cover	2				
3	Press with both thumbs on primary filter at the same time as you pull it out. This is to prevent the secondary filter from coming out together with the primary filter.	2				
4	Carefully tap the end of the air filter against a soft and clean surface	5				
5	Use clean and dry compressed air, blow the filter from the inside along the folds	5			compressed air	as stated
6	If there is the smallest hole, scratch, crack or other damage, the filter must be discarded	1			rag	1/4 kg
7	Install the primary air filter and the cover	4				
	Total	20				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 2

9.4. Hydraulic drain filter: replace






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	5	wrench	1-pc	 rag	1/4 kg
			screw driver	1-pc		
			plier	1-pc		
4	Place a container under the drain filter and turn the filter counter clockwise to remove it.	5			drain pan	1-pc
5	Fill the new filter with oil, thinly coat O-ring with oil.	1			new filter	1-pc
					hydraulic oil	as stated
6	Install the new filter	7				
	Total	20				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 2

9.5. Engine fan belt: check/replace






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	<p>Note: A loose fan belt can cause engine overheating, poor charging, and premature belt wear. A belt that is too tight can cause damage to the water pump, alternator bearing or belt.</p> <p>With the engine shut off, and the starter switch is in the "OFF" position and the controls are tagged, check the tension of the fan belt by pressing downwards on the belt, midway between the fan pulley and alternator pulley. The belt should flex approximately 10 mm (0.4 in.)</p>	5	 			
2	To adjust the belt, loosen the alternator adjustment plate bolts, adjust the belt tension and retighten the bolts.	10	wrench	1-pc	rag	1/4 kg
			screw driver	1-pc		
3	<p>Replace the belts if it is badly worn, greasy and severely cracked.</p> <p>Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable and if it is frayed or has pieces of material missing.</p>	5				
4	Install the new belts, make sure all pulley must be aligned. The grooves, bearings, shafts are in working order. Brackets are securely clamped. If damaged, replace.	15	 		fan belt	1-pc
5	Repeat activity nos. 1 and 2	15				
	Reminder: Check/adjust the tension of new belts at 50 hours intervals until tension is stabilized and thereafter, every 250 hours.					
	Total	50				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 3

9.6. Fuel filter: replace






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: Exchange filter after waiting for engine to cool. Be careful of fire hazards. Do not smoke.	2			container	1/2 pail
	Locate fuel filter inside engine compartment. Position a small container under the filter.				rag	1/4 kg
2	Unscrew fuel filter from head assembly. Discard fuel filter properly.	3	wrench	1-pc		
			screw driver	1-pc		
3	After cleaning filter head, install new fuel filter. Screw filter on head until gasket contacts head, and turn filter 1/2 turn more with a filter wrench. Note: Coat fuel filter gasket with fuel and fill fuel filter with clean fuel. This will help reduce fuel system priming.	5	filter wrench	1-pc	new fuel filter	1-pc
					fuel oil	as stated
4	If the fuel filter has been replaced, air may need to be bled using the following <u>FUEL SYSTEM PRIMING</u> : Loosen plug on top of the fuel filter head.	3				
5	Unscrew and pump the hand operated priming pump by the fuel injection pump. Pump priming pump until fuel is present at plug hole in fuel filter head.	5	 			
6	Tighten plug in fuel filter head.	1				
7	Continue to pump the priming pump until a strong resistance is felt. Screw the priming pump knob back into housing to lock the plunger.	3				
8	Start engine and look for signs of leaks. Repeat procedure if necessary.	3				
	Total	25				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 3

9.7. Air-conditioning system: check/clean





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: When a leak occurs, dirt will accumulate in the area where the leak is.					
1	All service and inspection of air-conditioning system should be performed with the starter switch in the "O" (Off) position.	1				
2	Check the hoses for damage and cracks.	1				
3	Inspect the condenser for dust and debris. Clean if necessary.	2			detergent	as stated
					water	
					rag	1/4 kg
4	Push the "A/C" switch on in order to energize the magnetic clutch. Check the magnetic clutch for dirt and interference.	2				
5	At correct belt tension, it should be possible to depress the belt approximately 10 mm (0.4 in.). Adjust if necessary.	2	wrench 	1-pc		
			screw driver	1-pc		
6	If the unit is equipped with an air filtration system which filters out dirt and dust particles from air being circulated into the operator's cabin, clean the air-conditioning outer and inner filters.	5				
7	Open the door in the left front of the machine, then remove the cover by loosening the four wing bolts.	5				
8	Remove the outer filter, then the inner filter and inspect for any damage. If the filter is damaged replace with a new one.	2				
9	Use compressed air to clean the filters. If the filter is very dirty, use a mild soap or detergent and water to clean it.	5			compressed air	as stated
10	If water was used, be certain the filters are completely dry. Install the filters and assemble it in reverse order.	5				
	Total	30				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 3

9.8. Alternator assembly: check/inspect





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	2	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the alternator assembly	30				
4	Overhaul and clean	40			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease, bushing for wear. Replace if necessary.	5				
6	Assemble the alternator and install. If possible, check the alternator ratings on bench testing machine.	30	bench testing machine	1-set		
7	Check the alternator belt tension by pressing downwards on the belt, midway between the fan pulley and alternator pulley.	5				
8	Adjust the belt tension by loosening the alternator adjustment plate bolts. The belt should flex approximately 10 mm (0.4 in.) Retighten the bolts.	5				
9	Run the engine and check for any jarring noise and excessive vibration.	2				
	Total	120				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 3

9.9. Starting motor: check/inspect



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: The battery disconnect switch must always remain turned on while the engine is running. When welding, servicing of electrical system or after finishing work, for safety the battery disconnect switch should be turned off.					
1	Inside the battery box, turn off the battery disconnect switch.	1				
2	Disconnect the battery terminals	1	wrench	1-pc		
			plier	1-pc		
			screw driver	1-pc		
			ampere volt multi-tester	1-set		
3	Pull down the starting motor	30				
4	Overhaul and clean	25			multi-purpose grease	250 gm
					1-inch paint brush	1-pc
					sand paper	1-pc
					rag	1/4 kg
5	Check the carbon brush for wear; bearing may have run out of grease; bushing for wear. Replace if necessary.	1				
6	Assemble the starting motor and install. If possible, check the starting motor ratings on bench testing machine.	30	bench testing machine	1-set		
9	Run the engine and check for any jarring noise and vibration.	2				
	Total	90				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 3

9.10. Roller drum scraper: adjust



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	If the scrapers are worn to such an extent that the scrapers do not rub against the drum, it must be adjusted at the clamp connection					
1	Switch off diesel engine and remove ignition key	1				
2	Loosen clamp connection	10	wrench	1-pc	rag	1/4 kg
3	Push scraper to the roller drum	1				
4	Tighten the clamp connection	10				
5	To apply the scrapers against the drum, throw the stop lever to I position	8				
	When installing a new scraper, make certain that the screws are at the lowest positions in the elongated holes					
	Total	30				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 3

9.11. Roller tyre scraper: adjust



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	If the scrapers are worn to such an extent that the scrapers do not rub against the tyre with the stop screw loose, it must be adjusted at the clamp connection					
1	Switch off diesel engine and remove ignition key	1				
2	Loosen the stop lever and lift the scraper console to the stop. Tighten the stop lever	5	wrench	1-pc	rag	1/4 kg
3	Loosen clamp connection	5				
4	Push scraper to the tyres. Establish a clearance of 10 mm between the tyres and the scrapers	5				
5	Tighten clamp connection	5				
6	Loosen the stop lever for a short time and retighten it again	10				
	When installing a new scraper, make certain that the screws are at the lowest positions in the elongated holes					
	Total	30				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 3

9.12. Roller drum damping elements (vibration):
check



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Vibration oscillations can spread in the ground over a wide area and are generated in circles around the roller drum and effect also the deeper ground. Do not switch in vibration function when driving across inclines or on underground					
1	Switch off diesel engine and remove ignition key	1				
2	Check the damping elements of the roller drum suspension for cracks.	4	screw driver	1-pc	rag	1/4 kg
3	If the damping element is damaged, replace with new one	10				
	Total	15				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 3

9.13. Water separator element: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Turn priming pump counterclockwise to unlock the plunger then turn shut-off valve clockwise 90 degrees	1	wrench 	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	Place a suitable sized container under the drain hose	1			drain pan	1-pc
					rag	1/4 kg
3	Open drain valve and drain the fuel from the water separator, afterwards close the drain valve	5				
4	Disconnect sensor connector	1				
5	Remove bowl assembly and set it aside for installation and remove filter element	5	filter wrench	1-pc		
6	Clean the inside surface of the filter head and of the bowl; check the condition of the O-ring. Replace the O-ring if damaged	30				
7	Apply a small amount of fuel to the gasket of the new filter; install the new filter by hand until it contacts the mounting surface. Tighten the filter	30			new filter	1-pc
					fuel oil	as stated
8	Install bowl assembly; reconnect sensor connector	5				
9	Turn shut-off valve counterclockwise 90 degrees	2				
10	Bleed the system	10				
	Total	90				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 4

9.14. Hydraulic oil: change





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Warning! Take care when changing the oil. Hot oil can cause burns on unprotected skin					
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	3	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc	rag	1/4 kg
4	Open the cover after removing the screws and remove O-ring then pull out the strainer.	20				
6	Place a suitable container under the drain plug of hydraulic tank	1			drain pan	1-pc
7	Remove the drain plug	3				
8	Drain the oil into the container. Wait till the last drop of oil for few minutes	20				
9	Reinstall the drain plug	5				
10	Clean the magnetic rings of strainer thoroughly. Check O-ring and if damaged, replace it with a new one and reinstall the strainer.	5			compressed air	as stated
11	Refill oil and reinstall the cover	20			hydraulic oil	as stated
12	Check the oil in the sight gauge.	1				
13	Perform test run to check for any leaks	10				
	Total	90				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 4

9.15. Hydraulic pilot filter: replace





Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Park the equipment on a firm, level ground	1				
2	Lower upper attachments to the ground, move the control lock out lever down to lock the system securely and shut down the engine	1				
3	Open access. Release the internal pressure of the hydraulic tank through air breather	2				
4	Place a container under the pilot filter.	1			drain pan	1-pc
5	Unscrew/remove the filter bowl or canister, O-ring and inner element. Note: The bowl/canister will be filled with oil. Use caution when removing this assembly.	5	wrench	1-pc	rag	1/4 kg
			 plier	1-pc		
6	Install a new inner filter element and O-ring. Apply a small amount of oil around the entire O-ring.	5			pilot filter element	1-pc
					o-ring	1-pc
					hydraulic oil	as stated
7	Reinstall the filter bowl/canister.	2				
8	After changing the pilot filter element, vent air from pump and check level of hydraulic oil tank.	3				
	Total	20				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 4

9.16. Hydraulic System: venting and priming

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Note: If pump is run without sufficient oil in the main hydraulic pump, damage can occur. Always vent pump of air after draining hydraulic system. With the engine stopped, remove vent plug to see if any oil is present.	3	wrench 	1-pc	rag	1/4 kg
2	If oil is not present, fill pump with oil thru port.	5			hydraulic oil	as stated
3	Install vent plug first.	2				
4	Start engine and run it for several minutes at low idle engine speed. This will pressurize the hydraulic oil tank and system.	5	 			
5	Slowly loosen vent plug several turns, until hydraulic oil flows out of plug. This shows that air has been released. Tighten the plug.	5				
	Total	20				



9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 4

9.17. A. Check/adjust engine valve clearance

B. Check/retight cylinder head bolt






Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
1	Open access	1				
2	Remove parts/accessories to give way for the adjustment of engine valve	5	flat screw driver	1-pc		
			cross screw driver	1-pc		
			plier	1-pc		
			combination wrench	1-pc		
3	Remove valve cover	5			rag	1/4 kg
4	Check/untorque cylinder head bolt	15				
5	Adjust valve clearance	30	feeler gauge	1-set		
6	After valve clearance adjustment, repeat the procedure in reverse order	25			sealant	1-tube
					gasket	1-set
7	Start the engine and check for leak and any distorting noise	5				
	Note: Follow procedure of engine valve clearance/adjustment according to manufacturer's guide and standards					
	Total	86				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 4

9.18. Turbocharger: check/clean



Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Important: Leave the engine running at low idling speed for at least a minute after start and a few minutes before it is stopped. This is to safeguard the lubrication of the turbocharger.					
1	Remove the oil filler pipe and drain pipe, then remove the intake air pipe connector and blower housing so that the blower impeller can be seen.	10	wrench	1-pc		
			screw driver	1-pc		
			plier	1-pc		
2	NOTE: excessive carbon or oil sludge adhering to turbocharger blower may lead to performance deterioration and possible damage. Using light oil as a cleaning agent, remove the carbon, sludge, and other dirt from the blower impeller.	5			light oil	as stated
					rag	1/4 kg
3	Pour in light oil thru the turbocharger oil filler and rotate the blower impeller several times to wash out the sludge.	5				
4	Rotate the impeller by hand at least one turn at speed to check that there is contact noise or catching inside. If the impeller does not turn smoothly, contact the equipment manufacturer for repair or replacement.	10				
5	If there is no abnormality, dry off the light oil with compressed air after inspection, then add engine oil.	5			compressed air	as stated
6	Reassemble in reverse order.	20				
7	Run the engine and if any jarring noises be heard and shows unusual vibration, it must be reconditioned or changed immediately.	5				
						
	Total	60				

9.0. Vibratory Roller

DPWH Property Code: Z18

Maintenance Activity: PM 4

9.19. Air conditioner refrigerant: check

Activity Number	Activity	Duration (minutes)	Tools		Materials	
			Tool Class	No. of unit	Material	No. of unit
	Note: Inhaling air conditioner refrigerant gas thru a lit cigarette or other smoking method or inhaling fumes released from a flame contacting refrigerant gas can cause bodily harm or death					
1	Run engine at about 1,800 rpm. Operate for a minimum of ten (10) minutes to stabilize the air conditioning system	10				
2	Press the "HI" fan speed switch to set maximum airflow	1				
	Put the temperature control switch in maximum cooling position					
	Press the "Internal Air Circulation switch					
3	Compare the flow of bubbles in the sight glass of receiver dryer in the following table:	1				
4	Amount of refrigerant: Almost clear. Any bubbles disappear. Normal; No bubbles are seen. High. Withdraw the system with the correct amount of HFC 134a refrigerant; A flow of bubbles is visible. Low. Charge the system with the correct amount of HFC 134a	8			rag	1/4 kg
	Important: Overfilling refrigerant can cause dangerous high-pressure and poor cooling action; and low refrigerant level can cause compressor damage					
	Total	20				

ACKNOWLEDGEMENT

This Bureau of Equipment (BOE) thru the office of the Bureau Director wishes to extend thanks and appreciation to the many construction and maintenance equipment distributors/suppliers that have supplied and made available the Operation and Maintenance Manuals and the use of TESDA Training Regulations Handbook and reference instructional materials in heavy equipment operation, and to the EOMD-Equipment Deployment and Operation Section's (EDOS's) engineers and staff who rendered their time and expertise to the development of various activities in this manual.

TORIBIO NOEL L. ILAO

Director IV, Bureau of Equipment

OSCAR O. ISIDRO

Chief, Equipment Operation and Maintenance Division (EOMD)

PETRONILO R. CARAMBAS, JR.

Engineer III

FRANCISCO D. JORGIO, JR.

Engineer III

MARIO L. MARASIGAN

Engineer III

WILFREDO DV. MAMUYAC

Mechanic III

JOAQUIN D. UY

Mechanic II

JOEMEL D. DE SAGUN

Engineer II

ALEXANDER T. MARAMARA

Engineer II

MANUEL C. DELOS SANTOS

Dredgeman Foreman (JO)

BIBLIOGRAPHY

Operation and Maintenance Manuals and Instructional Materials:

- Training Regulations Handbook for Heavy Equipment Operation, July 2007, TESDA
- Training Regulations Handbook for Heavy Equipment Servicing, December 2006, TESDA
- Training Regulations Handbook 1998, TESDA
- LG956L Wheel Loader, Shandong Lingong Construction Machinery
- Solar 180W-V Wheel Excavator, DOOSAN
- DX225LCA Crawler Excavator, Volvo Construction Equipment
- Super 1100-2/1300-2 Road Paver, Voge/Wirtgen
- H10 VV/H12 VV Tandem Roller, HAMM/Wirtgen
- CLA Series Dump Truck, MAN Force Trucks Pvt. Ltd
- CAMC 4x2, Hauling Star, MACRO Construction Equipment
- Heavy Duty Trucks, Hyundai Motor Company
- GDS11A-1 Motor Grader, Komatsu
- D21 Series Wagon and Pick-up, Nissan
- Lovol B and 1000 Series Diesel Engine, Tianjin Lovol Co.

NOTES:

NOTES: